# CUCKOO

**Electric Pressure Rice cooker/warmer** 

전기 압력 보온 밥솥

**Operating Instructions** 

사용설명서

CRP-FA06/FA08 Fuzzy Series

FA06 **Series**: 1.08L(2~6Persons) / 1.08L(2~6인분) FA08 **Series**: 1.44L(2~8Persons) / 1.44L(2~8인분)



**CUCKOO ELECTRONICS CO., LTD.** 



저희 쿠쿠 압력보온밥솥을 애용해 주셔서 대단히

사용 중에 모르는 사항이 있을 때나 기능이 제대로

Limited warranty ......44

이 사용설명서는 잘 보관하여 주십시오.

발휘되지 않을 때 많은 도움이 될 것입니다.

Thank you very much for purchasing "CUCKOO" Electric Rice cooker/warmer

Limited warranty ------ 44

Read all instructions before use. Save these instructions for future reference.

CONTENTS

# 모 차

감사 드립니다.

## 사용하기전에 BEFORE USING Important safeguards ----- 3 Specifications 4 제품규격 ……………………… 4 Caution for safety-----5 안전을 위한 주의 시항 ..... 24 Caution for use 8 사용상의 주의 사항 ……………………27 Name of each part ····· 9 각 부분의 0름 ......28 Function operating part ------ 10 기능 조작부의 설명 ......29 사용할 때 WHEN USING Before cooking rice ------ 11 취사 전 준비사항 …………………………30 Error Code and possible cause ...... 12 기능 표시부의 이상점검 기능 ......31 How to cook ------ 13 취사방법 .......32 MY MODE (Cuckoo Customized Taste Function) ...... 15 '쿠쿠 맞춤밥맛' 사용방법 ……………34 How to use "GABA (Brown rice)" -----16 현미발아 취사방법 ......35 To keep warm the cooked rice tasty ...... 19 보온/재가열 ......39 How to clean ······ 21 제품 손질 방법 ………………………41 고장 신고 전에 BEFORE ASKING FOR SERVICE Check before asking for service ...... 22 고장신고 전에 확인 하십시오……………42

# **IMPORTANT SAFEGUARDS**

- 1. Read all instructions before using this appliance.
- 2. Do not touch hot surfaces. Use handles or knobs.
- 3. To protect against fire, electric shock and / or injury to persons do not immerse cord, plugs, or Pressure Cooker Body in water or any other liquid.
- 4. Close supervision is necessary when this appliance is used by or near children.

  This appliance is not intended for use by young children or infirm persons without supervision.

  Young children should be supervised to ensure that they do not play with the appliance.
- 5. Unplug from outlet when not in use and before cleaning.

  Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- 6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
- 7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, and / or injury to persons.
- 8. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- 9. Do not use outdoors.
- 10. Do not let the cord hang over the edge of the table or counter, or touch hot surfaces.
- 11. Do not place on or near a hot gas or electric burner, or in a heated oven.
- 12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- 13. Do not use this appliance for other than its intended use.
- 14. Extreme caution must be used when moving an appliance containing hot oil or any hot liquids.
- 15. Oversized foods, metal foil packages, or utensils must not be inserted in the appliance as they may involve a risk of fire or electric shock.
- 16. A fire may occur if the appliance is covered or touching flammable material, including curtains, draperies, walls, and the like while in operation.
- 17. To reduce the risk of electric shock, cook only in removable container.
- 18. This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating. See "Operating Instructions."
- 19. Do not cook foods such as applesauce, cranberries, or other cereals macaroni or spaghetti. These foods tend to foam, froth, and sputter, and may block the pressure release device.
- 20. Always check the pressure release device for clogging before use.
- 21. Do not open the pressure cooker until the unit has cooled and internal pressure has been reduced. See "Operating Instructions."
- 22. Do not use this pressure cooker for pressure frying with oil.

# SAVE THESE INSTRUCTIONS THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

## ADDITIONAL IMPORTANT SAFEGUARDS

**WARNING**: This appliance generates heat and escaping steam during use. Use proper precaution to prevent risk of burns, fires, or other injury to persons or damage to property.

- 1. Keep hands and face away from Pressure Release Valve when releasing pressure.
- 2. Take extreme caution when opening the Lid after cooking. Serious burns can result from steam inside.
- 3. Never open the Lid while the unit is in operation.
- 4. Do not use without the inner Pot in place.
- 5. Do not cover the Pressure Valve with anything as an explosion may occur.
- 6. Do not touch the inner pot and any heating parts, immediately after using. Let the unit cool down completely first.

# SHORT CORD INSTRUCTIONS

## Note:

- **A.** A short power-supply cord (or cord set) is to be provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
- **B.** Longer cord set or extension cords are available and may be used if care is exercised in their use.
- **C.** If a long cord set or extension cord is used.
  - (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
  - (2) if the appliance is of the grounded type, the extension cord should be a grounding-type three-wire cord, and
  - (3) the longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over accidentally.

This appliance has a polarized plug: (one blade is wider than the other).

As a safety feature, this plug will fit in a polarized outlet only only one way.

If the plug does not fit fully in the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician.

Do not attempt to defeat this safety feature.

# SPECIFICATIONS / 제품규격

모델명(Moo	del Name)	CRP-FA06 Fuzzy Series	CRP-FA08 Fuzzy Series	
전원(Powe	r Supply)	AC 120V, 60Hz		
소비전력(Power Consumption)	취사시 (Cook)	990	WC	
Approx(약)	보온시 (Warm)	110	WC	
	백미 (Glutinous Rice)	0.36~1.08L (2~6cups)	0.36~1.44L (2~8cups)	
	잡곡 (Mixed Rice)			
취사용량	김초밥 (Normal Rice)			
(Cooking Capacity)	현미발아 (GABA)	0.36~0.72L (2~4 cups)	0.36~1.08L (2~6cups)	
	묵은쌀 (Dried Rice)			
	누룽지 (Nu Rung Ji)			
	백미쾌속 (Turbo Glutinous Rice)			
전원 코드 길이(Po	wer Cord Length)	1.0m		
사용압력(F	Pressure)	78.4KPa(0.8kgf/cm²)		
중량(W	eight)	5.4kg 5.8kg		
	폭 (Width)	26.6cm		
치수(Dimension)	길이 (Length)	34.4cm		
	높이 (Height)	26.2cm	29.2cm	

# HOW SERVICE IS HANDLED

**USA** The East and the Central Districts

Tel. No. (718) 888-9144

The West and the Central Districts

Tel. No. (213) 687-9828

Canada

**TORONTO** 

Tel. No. 416 878 4561 / 905 707 8224

**VANCOUVER** 

Tel. No. 604 540 1004

# CAUTION FOR SAFETY

- ▶The following must be observed to use the product safely and correctly to prevent accident and dangerous situations.
- ▶ Warning' and 'Caution' are different as follows.

## **⚠** WARNING

This means that the action it describes may result in death or severe injury.



This means that the action it describes may result in injury or property damage.



- This sign is for reminding something may cause problems under the certain situation.
- Please read and follow the instruction to avoid any harmful situation.
- 0
  - · Indicates a prohibition
  - Indicates an instruction

# **WARNING**


# Do not use the cooker near hot things such as stove, gas stove or direct ray of light.


▶It can cause an electric shock, fire, transformation or discoloration.



# Please pay careful attention against water and chemicals.

▶It can cause an electric shock or fire.





▶ It can cause burns, electric shock or injury.



Do not let the cooker contact any water by sprinkling water on the cooker.

▶It can cause an electric shock or fire,

▶If it contact water, please separate power cord and contact dealer and service center.



Do not cover the automatic steam outlet or pressure weight with your hand or face.

- ▶It can cause burns.
- ► Especially be careful to keep it out reach of children.

Do not plug or pull the power cord with wet hands.


▶ It can cause an electric shock.





Use a single socket with the rated current above 15A.

- ►Using several lines in one socket can cause overheating resulting in fire.
- ►Use the extension cord with the rated current above 15A.



- ▶It can cause an electric shock, short circuit or fire.
- ▶If the plug were damaged, contact dealer or a service center.




# CAUTION FOR SAFETY

# **WARNING**


## Do not press heavy things on the power cord.

▶ It can cause an electric shock or fire.



Do not use abnormal pot and do not use without inner pot.

▶It can cause an electric shock or fire.



Clean any dust or alien substance off the temperature sensor. heating plate and inner pot.

▶It can cause a system problem or fire.

## Do not open the top cover while in heating and cooking.


- ▶It can cause burns.
- ▶If you need to open the lid while cooking, keep pressing the cancel button for 2 seconds and confirm internal steam released completely turning the pressure weight over.



- ▶It can cause fire, electric shock or injure.
- ► For repair, contact dealer or the service center.

## Do not insert metal objects such as pin and wire or any other alien substance in the automatic steam exhaust outlet or any other slot.

- ▶ It can cause an electric shock or fire.
- Especially be careful to keep it out of reach of children.




- ▶Do not insert cleaning pin to other parts except to the valve hole of the pressure weight.
- ▶It can cause an electric shock or fire.
- ▶Especially be careful to keep it out of reach of children.

## Do not bend, tie or pull the power cord by force.


Remove an alien substance

▶It can cause an electric shock or



## Do not turn the Lock/Unlock Handle to "Unlock" in cooking.

- ▶The hot steam or any hot content within the cooker can cause burns.
- ► After you finish the cooking do not try to open the cooker by force until the steam is completely exhausted.



- ▶It can cause a transformation or a breakdown.
- ▶It can cause an explosion by pressure.

## Do not use on a rice chest or a shelf.

- ▶Do not press the power code between furniture. It can cause an electric shock resulting in fire.
- ▶When use on furniture automatic steam releasing can cause damage, fire and an electric shock.



## the cushion. Please avoid using it on an unstable location easy to be fallen down

Use product at the flat place. Do not use on

- ▶It can cause a transformation or a fire
- ▶It can cause burns or breakdowns.
- ▶Be careful to install the power cord which does not disturb to pass.



## Don't spray or put any insecticide and chemicals.

- ▶It can cause an electric shock or fire.
- ▶In case cockroach or any insects get inside of the cooker please call a dealer or a service center.





# CAUTION FOR SAFETY

# **CAUTION**

## Do not touch the metallic surface of the inner pot, heating plate and pressure weight after cooking or warming.

- ▶It can cause burns.
- ▶ Remaining hot steam can cause burns when you tilt the pressure weight while and right after the cooking.

## Do not use over the maximum capacity.

- ▶It can cause overflow or breakdown.
- ▶Do not cook over capacity stated for cooking of chicken soup and congee.



## Do not pull up the cooker by holding the inner pot handle.

▶If can cause problems and dangerous situations. There are portable handles on bottom right and left side of the cooker. Hold the handles with both hands



## After you finish the cooking, do not try to open the cooker by force until the steam is completely exhausted.

- ▶The hot steam or any hot content within the cooker can cause burns.
- ▶Be careful with burn by the steam when you open the top cover after cooking is done.



## Be careful about the released steam of vent.

- ▶When the steam is released don't be surprised.
- ▶Please keep the cooker out of reach of children.

and move it carefully.



## Don't use the cooker near the magnetic field. Do not drop the cooker or impact.

- ▶It can cause burns or breakdown.
- ▶It can cause the safety problem.

▶It can cause electric shocks or fire.

►Use AC 120V only.



## Don't use to be used for various purpose for inner pot.

- ▶ It can cause the transformation of the inner pot
- ▶It can cause to spill the inner coating.

## Please call the customer service if the inner pot coating rises.

- ▶Oven coating may wear away after long use.
- ►When cleaning the inner pot, do not use tough scrubber, metallic scrubber, brush, abrasive metallic etc. (Refer to page 21)



Please surely pull out the plug when not in use.



## Please use the cooker for an original purpose.

►It can cause the transformation or smell.



## Please clean the body and other parts after cooking.

- ▶It can cause the transformation or smell.
- ►Use dry kitchen cleaner or sponge to clean the inner pot, since rough scrub or metallic ones might let coating rise.
- ▶Depending on the using methods or user's circumstances inner pot coating might rise. Please call the customer service for those cases.

## Always turn the Lock/Unlock Handle to "Lock" when not in used.

▶It can cause the transformation by remaining pressure.



## Please contact dealer or service center when strange smell or smoke is occurred.

First pull out the power cord.



# CAUTION FOR USE

## Do not try to close the top cover by force. It can cause problems.

▶ When opening/closing the top cover.



- Locate the handles of the inner pot on the slot of the main unit. (Refer to the following figure.)
- Open and close the top cover with the Lock/Unlock handle located on "Unlock".

## ► When cooking/warming the rice.




- Cook and warm the rice with the Lock/Unlock handle located on "Lock".
- When steam is full inside the pan, the Lock/Unlock handle will not turn at this time twist the pressure weight and let the steam out.
- When the cooker is not properly cleaned, it can cause smells. Clean the top cover frequently.
- If there are any rice or alien substances on the oven packing or on the inner side of the inner pot, it can cause the steam to leak. Therefore the rice may be under-cooked and crumbly.

Wipe the top cover with a wet ···· cloth that has been squeezed out of all the water

Wipe the main unit with a wet cloth that has been squeezed out of all the water

If there is any alien substance on the temperature sensor carefully wipe it out without damaging the metal plate



- ➤ Check if there is any rice or alien substance on the oven packing.
- ► Make sure you clean the steam control vent before and after use
- Wipe the inner upper and outer of the inner pot of any alien substance.
- \* Don't use to be used for various purpose for inner pot.
- ▶It can cause the transformation of inner pot
- ▶It can cause to spill the inner coating.

## If the valve hole of the pressure weight part is clogged, punch it with the cleaning pin.

- The valve hole of the pressure weight allowing the escape of steam should be checked regularly to ensure that it is not blocked.
  - If you use the valve hole of pressure weight as it is blocked, the hot steam or any hot content within the cooker can cause injury.
- \*\* Do not use a Cleaning Pin for other use except cleaning for the valve hole of the pressure weight.




How to disassemble the pressure weight

- ▶ Under the Lock/Unlock handle is locked (located on "Lock") turn the pressure weight counter-clockwise while pulling it up, and pull it out.
- ▶ Punch the clogged valve hole with the cleaning pin and reassemble it by turning it clockwise.
- ▶ When the pressure weight is properly assembled, it can freely be turned.

# NAME OF EACH PART

warming the rice)



How to clean the soft steam cap

1. Detach the soft steam cap like the picture.



Press the hook, in the back, and follow the arrow to detach and clean. Make sure you clean frequently with a sponge or a neutral detergent.




3. Assemble the vent so that it fits into the groove perfectly.




 After you attach the soft steam cap to fit into the groove, press 'A' part firmly to assemble the soft steam cap into the product.



\*\* Do not touch the surface of the soft steam cap right after cooking. You can get burned.







# FUNCTION OPERATING PART

## Ready to Operate

The red light will be on when it's ready to operate.

## The automatic voice guide function

After press the Cancel button for 2 seconds, the automatic voice guide function would be ON or OFF.

"VOICE" is shown on the display when it's ON.

## Turbo Lamp

The red light will be on when it's ready to operate turbo fuction.

Pressure Cook

/Turbo Button

Use it for cooking the rice.

Cancel Button

Use it for canceling the


(Refer to page 13, 14)

## Keep Warm/ Reheat Button

Use for Warming or reheating the cooked rice right before eating. (Refer to page 19, 20)

## Timer Button

Use it by presetting the time when you desire specific time to eat. (Refer to page 18)



## selected function (Refer to page 23)

## Display

When cooking: First the "[ ] " goes around,

and the remaining cooking time will be displayed in minutes.

When warming: The warming time will be

displayed in hours.

When presetting: The finishing time for the preset cooking will be displayed.

## Hour/Minute/My mode Button

- Use it for setting the current time and presetting time. (Refer to page 10)
- Use it to set "My mode" function (Refer to page 15)

## Menu Button

- · Use it for selecting, the glutinous rice, normal rice, mixed rice etc.(Refer to page 14)
- · Use it to control the strength and weakness of warming. (Refer to page 19)

## How to set time

1. Connect the power plug.



2. Press the Hrs. Min button more than 1 second.



Set the current time using the Hrs Min

button. Press the button longer than 1 second.



It will automatically start in 7 seconds.

- ▶After you press the (H,S), (Min) button to set the time, pressing any buttons except (H,S), (Min) or (Second buttons will also enter the set value.
- ▶If the current time is not correct, the rice will not finish cooking at desired time.
- ▶During warming mode press the Cancel button to set the time. After setting the time press Keep warm button: displays " [] "



Make provisions for any electrical failures and clock function, unit contains lithium battery. Battery life is about 3 years depending on using condition.

Don't short circuit, place in fire or near heat source, disassemble, or recharge.

0

t

e

# BEFORE COOKING RICE

# Wash the rice thoroughly

Measure the amount of rice you want to cook using the measuring cup and wash it thoroughly.

Wash the rice until the water becomes clear. This makes the rice taste better. (Wash at the other pot.)

- \* 1 cup applies to 1 person.
- ▶ Correct method for using the measuring cup.








# 2 Measure the water accurately.

After you wash the rice thoroughly, put it in the inner pot, and adjust the water level according to the marked line.

Place the inner pot on a leveled surface and adjust the amount of water.



- \* About water scale
- 8 persons jar(FA08 series)
- ▶ Glutinous rice, mixed rice, Nurungii
  - : Pour water to scale of "GLUTINOUS"

    Max. capacity: Glutinous rice-8 persons

    Mixed rice and Nurungji-6 persons
- ▶ Normal rice. GABA, dried rice
  - : Pour water to scale of "NORMAL, GABA" Max. capacity: 6 persons

- 6 persons jar(FA06 series)
- ▶Glutinous rice, mixed rice, Nurungji
  - : Pour water to scale of "GLUTINOUS"

    Max. capacity: Glutinous rice-6 persons

    Mixed rice and Nurungji-4 persons
- ▶Normal rice, GABA, dried rice
  - : Pour water to scale of "NORMAL, GABA" Max. capacity: 4 persons

## Rice storing method

- Keep the rice where it is cool and shady.
- If the rice is kept dry it will not be good and even cause the cooked rice to smell.
- \*\* Place to avoid: Hot places where boiler pipe passes by / Places under direct sunlight / Humid places.
- \*\* It is recommended that you buy rice in small packages because the quality can be degraded when stored for a long period of time.

# BEFORE COOKING RICE

**3** Wipe the water and put it in.

Wipe the water on the inner pot with a dry cloth and put it in the main unit. Then connect the power plug.

- ► Top cover will not close if the inner pot is not placed correctly in the main body (Place the inner pot to the corresponding parts of the main body)
- ▶ If there is any alien substance on the temperature sensor or the bottom surface of the inner pot(oven), wipe it off before putting the pot into the main unit.
- ▶ Wipe the top cover heating part well before cooking the rice.

  If the top cover heating part is not cleaned well it can cause smells and discoloration.
- ▶ If there is any rice or alien substance on the oven packing or inside the upper part of the inner pot, the steam will leak. This will make the rice under-cooked and crumble.



After setting the Lock/Unlock handle to "Lock", check the pressure weight is horizontal and the pressure Lamp is on.

- ▶ If you press the cook button without setting the Lock/Unlock handle to "Lock" the cooker will not operate. You will hear "beep beep beep" sound and " £ □ 1" is shown in the LCD.
- ▶ If it is hard to close the top cover due to internal pressure, tilt the pressure weight. This will make it easy to close.



Temperature

Sensor

# ERROR CODE AND POSSIBLE CAUSE

\* When the product have any problems or use it inappropriately you can see the below marks.

▶ When the inner pot is not placed into the unit.

E \_ \_

► Temperature sensor problem. (Consult the service center and dealer.)

E 0 1

▶ When pressing the and time botton, while the Lock/Unlock handle is on "Unlock". Turn the Lock/Unlock handle "Lock".

E 03

▶ It shows when you keep boling water or the unit doesn't operate at all. (Consult the service center and dealer.)

13 Ko

▶ When setting preset time longer than 13 hours Set the preset time within 13 hours(Refer to page 18.)

# HOW TO COOK



## **Glutinous Rice Cooking Method**

Press the Menu button and select the menu.




Press the Press







- ▶ Check the pressure weight is horizontal before cooking
- ► The menu can only be selected with all the functions canceled. If the Menu button doesn't work press the Cancel button and then press the Menu button.
- ► Every time you press the Menu button, the following menu will continuously repeat.



- ► Check the Lock/Unlock handle is set to "Lock" and press the button.
- ▶ It will start to cook with the " [ ] " mark going around clockwise.
- ► Pressing H's button will display the rate of completion.

  Pressing Min button will make "[-]" "go clockwise.

  (The rate of completion indicates each steps of cooking, not indicates the rate of cooking time.)
- ▶ When it comes near the finishing time, the remaining time will be displayed in minutes.



# 3 Mix the cooked rice well, after the cooking is finished.

- During the cooking process, the pressure is automatically controlled with the steam discharged through the pressure weight.
- 3 minutes before the cooking is completed you will hear the "beep" sound and the steam will be automatically discharged. At "Normal rice" mode, the steam will be discharged once during cooking and once three minutes before the proper degree of cooking is ended.
   (Don't be surprised and be careful not to cause any burns.)
- When the cooking is finished, the "beep" sound will go off 5 times and switch to warm.
- When it is switched to warm, open the top cover and mix the cooked rice well.
- In case of a power failure during the cooking process, it will be delayed for the time the power is shut down. But if the power is shut down for a long time, the condition of the rice will not be good.
- When the handle doesn't turn to "Unlock", tilt the pressure weight a little to release the internal pressure and it will make you much easier to open it.



# HOW TO COOK



## 메뉴

**Glutinous :** When you want to have sticky and nutritive white rice. **Normal:** When you want to have a little more sticky and nutritive

white rice than Glutinous rice.

Mixed: For cooking together with brown rice and some other kinds of grain.

GABA: For cooking germinated brown rice. (Refer to page 16, 17)

**Dried:** For cooking Dried rice.

- If cooked with old, or dried rice, the boiled rice may become crumbly or underdone.
- For dried rice which has been more than one year since its harvest or by being left in a dry place for a long time, cook in the "Dried Rice Cooking Process" for a better result. (melanizing may occur according to the keeping conditions or moisture)
- ▶ Wash rice sufficiently until wash water becomes clean.
- ▶ New rice gives a better taste. But in smaller quantity.
- ▶ Dried rice may give out odor, as well as poor taste.

Nu Rung Ji(Scorched rice): Have scorched rice when cooking done.

- When cooking is completed, take out boiled rice.
- The "Nu Rung Ji" on the jar bottom can be prepared for your taste. (e.g. scorched rice tea)
  - ▶ "Nu Rung Ji" is allowed up to 6 persons in an 8 persons capacity jar, 4 persons in a 6 persons jar.
  - ▶ For "Nu Rung Ji" cooking, set the water volume at "GLUTINOUS" level.

Sweet Pot.: Steams sweet potato using the steam plate included.

**Multi cook**: The unit cooks all kinds of stew by setting cooking time.

- Basic setting time is 20 minutes.
- Available setting time is 10-90 minutes.
- Each time you press (Hrs) the time increases 5 minutes.
- Each time you press Min the time decreases 5 minutes.
- The Multi cook function will start if you press button after setting the time.
- Pressing  $\frac{\mu_{rs}}{\mu_{ln}}$  button will display the rate of completion. Pressing  $\frac{\mu_{ln}}{\mu_{ln}}$  button will make " $\mathcal{L}^{-3}$ " go clockwise.

\*Please refer to the cooking guide

## Cooking time for each menu

	Menu	Glutinous	Turbo Glutionus rice	Normal	Mixed	GABA	Dried	Nu Rung Ji	Sweet Pot.	Multi cook
6 Persons	Cooking Capacity	2~6 Persons		2~4 Persons						Refer to
jar	Cooking Time	28~36 minutes	18~24 minutes	32~39 minutes	46~49 minutes	48~52 minutes	38~42 minutes	37~42 minutes	32minutes	the cooking
8 Porcons	Cooking Capacity	2~8 Persons			2~6 P	ersons			4개 (150g이하)	guide
Persons jar	Cooking Time	31~37 minutes	18~27 minutes	32~43 minutes	46~53 minutes	48~57 minutes	38~43 minutes	37~44 minutes	34minutes	

<sup>\*</sup> Note: If each sweet potato is bigger than 150g, please split into smaller pieces.

### Turbo function for Glutinous rice

- ▶ Press twice button after choosing the "Glutinous" and it will switch to quick cooking and shorten the cooking time.(It takes about 18 minutes when you cook the Glutinous rice for 2 persons.)
- ►The preset time function is not for Glutinous rice turbo cooking.
- ▶The turbo cooking function is allowed up to 6 persons in an 8 persons capacity jar, 4 persons in a 6 persons jar.
- ▶If you soak the rice in water for about 20 minutes before cooking the rice and then cook the rice in turbo cooking course, the rice will taste good.

After cooking Multi cook etc, the smell may permeate into the unit, use the unit after cleaning the rubber packing and lid part according to page 8, 21

# MY MODE (Cuckoo Customized Taste Function)

## What is "MY MODE"?


▶ Cuckoo's patented technology based on variable circuit design. User can select the degree of "softness" and "glutinosity & tastiness" to meet a user's specific taste.

## MY MODE Function

- ▶Longer "SOAK" Time: rice becomes soft and glutinous (selectable in 4 steps)
- ▶Longer "HEAT" Time: rice becomes tasty (selectable in 4 steps) [melanizing will occur]
  - \* Above 2 functions can be selected both or individually.

## How to use "MY MODE"

- In the cooking time selecting menu, press button. "SOAK" will be activated, as shown in the figure below
- "MY MODE" function applies to "Glutinous, Mixed, GABA, or Dried" menu.
  - Unless one of "Glutions, Mixed, GABA, or Dried" menu is selected, button cannot be entered.



Set-up time is stored until the next reset. No need to set-up at every cooking.
During Cooking, Warming and preset time cooking modes, "SOAK" and "HEAT" Time cannot be readjusted.

## **Cautions**

- 1. 'MY MODE' function may influence scorching or cooking quality. Ensure that cooking time is not changed, by children.

  \*Default settings are "SOAK" Time 0 min., "HEAT" Time 0 min.
- 2. "MY MODE" function may elongate cooking time according to set-up time.
- 3. Scorching of rice may occur by longer "HEAT" Time.

# HOW TO USE "GABA (Brown rice)"

## What is Germinated Brown rice?

▶ Brown rice has richer nutrients than polished rice. However, brown rice is rather tough and harder to be digested.

By a least germination, the enzymes in the brown rice are activated, generating nutrients and more digestible.

## Tips to Buy Quality Brown Rice

- 1 Check the dates of harvest and pounding.
- ▶ The dates should be within 1year from a harvest, 3 months from pounding.



(Regular brown rice) (Poor brown rice-Missing embryo)



(Poor brown rice - Empty ear and nit fully owned brown rice)


## 2 Inspect rice with your eyes.

- Check that embryo is alive
- Rice surface should be light yellow and glazing. Whitely stirred up surface, or darkish colored Brown rice is not suitable for a germination
- Avoid fractured, not fully corned, or empty ear. Empty ear may generate odor during germination and bluish- nor corned Brown rice cannot be germinated.

## Features of Germinated Brown rice

Germinated Brown rice increases nutrients and enhances taste which is a weak point of brown rice. Germinated Brown rice also improves digestibility.

- ▶ Taste will be greatly enhanced.
- ▶ Digestive and rich in nutrients.
- Diatetic hormone is generated improving digestibility.
- ▶Good as a health food for children or students.
  - Rich with dietary fiber.
- ▶Germinated brown rice has rich GABA (Gamma Amino Butryc Acid)
  - GABA promotes metabolism in liver and kidneys, suppresses neutral fat, lowers blood pressure, promotes metabolism in brain cells - these effects have been proved by medical science.



<Comparison of Germinated brown rice's nutrition and Glutinous rice's(6 hours) nutrition.>

- ▶Phytic acid 10.3Times
- ▶Ferulic acid 1.4Times
- ►Gamma-orizanol 23.9Times
- ►Gammma-aminobutyric 5Times
- ▶Inositol 10Times
- ▶Food fiber 4.3Times

Based on japan food analysis center

# HOW TO USE "GABA (Brown rice)"




## Using "GABA" Menu

# In order to promote germination, soak brown rice for 16 hours in water.

## **Method of Pre-germination**

- ▶ Put washed brown rice in an appropriate container, pour sufficient water to soak the rice.
- ▶ Pre-germination shall not exceed 16 hours. Make sure to wash rice clean with flowing water before using "GABA" menu. Be careful that too hard washing may take off embryos which generate the germination.
- ▶ Unique smell may be generated according to the soaking time of pre-germination.
- ▶ When pro-germination has been completed, wash the rice and put in inner pot (Oven). Pour appropriated volume of water, and use "GABA" menu.
- ▶ In summer or hot temperature environment odor may be generated. Reduce germination time and wash clean when cooking.
- 2 Set the Lock/
  Unlock handle
  at "Lock", press
  button to
  select "GABA".



Default setting: 2 Hours

► When the "GABA" is selected, "2H" is indicated in the display.

- Press Hrs and Min buttons to set time.
- ▶ Pressing button increases germination time by 2 hour.
- ▶ Pressing Min button decreases germination time by 2 hour.
- ▶ "GABA" time can be set-up by 0, 2, 4, 6 hours.
- If "GABA" time is set "0" hours, pressing button will start cooking immediately. To cook without germination or cooking germinated Brown rice, set the time at "0".



3 more hours for germination

- ▶Pressing button will begin the "GABA" process, after which. cooking will begin immediately.
- ▶During "GABA" mode, "COOK" indicator will be lit together with the germination time left.

## Precautions for 'GABA' Cooking (no cooking preset time allowed)

- ▶ If smaller germ is preferred, omit pre-germination process. Select "GABA" menu, set-up appropriate germination time, and start cooking (nutrient ingredients do not vary significantly by the size of germ).
- ▶ During hot seasons, longer germination time may generate odor. Reduce germination time.
- ▶GABA cooking is allowed up to 6 persons in an 8 persons capacity jar, 4 persons in a 6 persons jar.
- ▶City water can be used for germination. However, spring water is recommended. Germination may not be properly performed in hot or boiled water even after cooling.
- ▶Germination rate, germ growth may differ by the Brown rice kind, condition or period of storing, etc.
  - Germinated brown rice is sprouted brown rice. Germination rate and growth may differ by the Brown rice kind.

The brown rice should be within 1 year from harvest, and not long since pounded.

# HOW TO PRESET THE TIMER

- ▶ Put it in the inner pot with the measured water after wash the rice and turn the Lock/Unlock handle to "Lock".
- ▶ Presetting time is the time when the rice cooking is completed. (According to the amount of rice the finishing time may vary)

## Check if the current time and the menu are correct.

- Refer to page 10 for the time setting method.
- If the current time is not set correctly, the presetting time also be incorrect.(Make sure not to change A.M. and P.M.)
- If the menu is incorrect, press the Menu button and select the desired menu.
  - \* Caution : Press (Hrs., Min) button to set a cooking time, When use the Multi cook preset mode.

## Press the Timer button.

- If you press the button, the "PRESET" sign will be displayed with the preset time.
- After pressing button, set the preset time within 7 seconds.
- The default for set time is 6:30 AM
- If you press the time button without setting the lock/unlock handle on the top cover to "Lock", the "F [] | " sign will be on the display and don' t operate.





## Set the presetting time.

• Set the presetting time with the Hrs and Min button.

\* If the preset time is already correct, you do not need to set time again.

Example) When you want to eat the rice at 7:30AM.

Press the press the press the button (The "PRESET" sign will be displayed) and then press the

button, set time at 7 hours. And press the who button, set time at 30 minutes.



# 4 Press the আম button.

- The "PRESET COOK" will be displayed.
- Press the button when you want to cancel the preset cooking.
- \*\* The preset time will be stored. If you want to cook the rice to the preset time already entered, press the button and then press the button.
- \* If you want to check the current time during the Timer cooking, press the (Hrs) or (Min) button for 2 seconds.





## Precautions for preset cooking

- ▶ If the rice is old and very dry, the result of the cooking may not be good.
- ▶ If the rice is not well cooked increase the amount of water about half-scale.
- ▶ Press with button and restart to change the preset time.
- ▶ Set the presetting time to no more than 13 hours especially if the presetting time exceeds 7 to 8 hours during the summer time, the rice can smell bad.

Preset time will be changed automatically and displays " 13 H<sub>D</sub> " when setup time exceeds 13 hours.

▶ If the preset time is shorter than cooking time in the below table, the cooking starts immediately.

## W Using range of preset time for each menu

Menu	Glutinous	Normal	Mixed	Dried	Nu Rung Ji	Sweet Pot.	Multi Cook
Using range of preset timer (6Persons jar)	From (37minutes + My mode) to 13 hours	From 40 minutes to 13 hours	From(50minutes + My mode) to 13 hours	From (43minutes + My mode)to 13 hours	From 43 minutes to 13 hours	From 33 minutes to 13 hours	From(Setting time+1minutes) to 13 hours
Using range of preset timer (8Persons jar)	From(38minutes + My mode) to 13 hours	From 44 minutes to 13 hours	From(54minutes + My mode) to 13 hours	From (44minutes + My mode) to 13 hours	From 45 minutes to 13 hours	From 35 minutes to 13 hours	From(Setting time+1 minutes) to 13 hours

# TO KEEP WARM THE COOKED RICE TASTY




## How to keep warm

- ▶Using Keep Warm function for more than 12hours may cause discoloration or an objectionable odor in the rice.
- ▶During keep warm and reheat mode, set the cover lid handle at "Lock" (Could impact on a keep warm function or a breakdown of the clamp knob)
  - After the cooking process is finished it is automatically switched to warming function. Make sure to mix the cooked rice well as soon as the cooking process is completed with the rice scoop (within 5 minutes)
  - Do not keep the scoop inside the pot while warming the rice.
  - When using a wooden scoop it can cause serious bacteria and odors.
  - The mixed and brown rice cannot be in such good condition as white rice while in warm function due to their characteristics. Therefore do not keep mixed and brown rice in function for a long period of time.
- If the amount of rice inside the pot isn't that much, keep it at the center of the pot.
- Do not warm the cold rice or do not mix the cold rice with the warm.
- Always keep the power connected while warming the rice. If you turn the lock/unlock handle to "Unlock", the "UNLOCK" will be displayed. But the rice is still in warming function. The warming efficiency is better when the handle is kept at "Lock".
- Because there will always be alien substances on the internal side of the top cover(heating part), always remember to clean the top cover before using.
- During warm mode, the rice can turn white and rise. In this case, mix the rice.

## Controlling method of warming temperature

 When the color of the rice hasn't changed but the rice smells bad, or when the rice feels cold. Raise the warming temperature about 1~2℃



After pressing the

Press the (Keep Wiston Button





for 5 seconds over.

- \*The setting temperature when take the products out of warehouse can be different from an operating anual.
- When the color of the rice turns yellowish and rice smells bad.

Reduce the warming temperature about 1~2 ℃

This can be done according to the same method but this by pressing the win button.

- During the warming mode, the strength and weakness of warming can be readjusted.
  - -Press Menu button to enter Warming L/H Control Mode (default: H)
  - -Pressing Menu button alternates  $H \rightarrow L, L \rightarrow H$ 
    - H: select when much water runs-off from top cover when opening
    - L: select when the rice near the jar becomes too softened
  - -After 7 seconds, set value will be entered automatically.(Pressing any buttons except went set value)

It will automatically

start in 7 seconds

and My buttons to

complete the setting.

Press Turbe

- -During the setting, pressing and button will exit from the Setting Mode without changing the preset value
- During the warming mode, warm temperature is not adjustable.

After pressing button and press button for 5 seconds to set the warming temperature.


# TO KEEP WARM THE COOKED RICE TASTY



## Reheating Function (It reheats cooked rice like it has just been cooked.)

- ▶The reheating function only works while warming the rice.
  - Mix the warmed rice so that the surface is flat.

## While warming.....





- Keep the surface flat keeps the temperature of the rice constant and also reduces the dryness.
- During "WARM" mode the current time is shown by pressing "Min" button and the warm processing time is shown by pressing "His" button.

# 2 Check if the Lock/Unlock handle is set to "Lock" and press the (even Rehear) button.




- The " [ ] " mark rotating clockwise.
- Pressing Hrs button will display the residual time.
   Pressing Min button will make "[]" "go clockwise.
- The reheating course will be completed in 9 minutes with the "beep" sound.

## When the reheating is completed

 Mix the reheating rice well. If you reheat the cooked rice several times, it will degrade the taste of the warmed rice.
 Use it once or twice a day.

## When odors are rising during the warming mode

- Clean the lid frequently. It could produce bacteria and odors.
- ▶ Although it appears to be clean, the bacterias may cause odor during keep warm mode. So sterilize with a cloth has been boiled in hot water. Set the water to scale 4 of, "GLUTINOUS" and add 15cc of vinegar into the inner pot and boil pressing the (ancel button for 20-30 minutes.
- ▶ After you cook soups and steamed dishes clean the inner pot properly to prevent rice from smelling.




# TO KEEP WARM THE COOKED RICE TASTY

When cleaning the cooker always pull the power plug with dry hands and clean it after the cooker is fully cooled off.

## Clean the main body

When cleaning the top cover of the main body, do not use benzen, thinner, detergent etc,


- ▶ It can cause discoloration or transformation.
- ▶Wipe it with a clean cloth.
- ▶Do not wash the main body.



# Clean the inner pot and inside the top cover

When cleaning the inner pot, do not use tough scrubber, metallic scrubber, brush, abrasive material etc.

- ▶The coating can come off.
- ▶Clean it with kitchen cleaner and sponge.



## Clean inside the top cover


Soak the cloth in hot water and squeeze out the water. Use this cloth to clean inside the top cover of any alien substance.



## Clean the inside main body


After taking the inner pot out, clean the bottom surface (especially the surface temperature sensor and heating plate) of before using.

▶Incorrect temperature reading from the sensor can lead to or malfunction or even cause fire.




## Clean the dew dish

▶Empty the water out of a dew dish after cooking or keep-warming. Remaining the water in the dew dish cause bad smell.



# Clean the valve hole in the pressure weight



Do not use a cleaning pin for other use except cleaning for the valve hole of the pressure weight.

# CHECK BEFORE ASKING FOR SERVICE

\* If there is a problem with your cooker, check the following details before requesting service to your dealer. Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following			
When the rice is not cooked.	button is pressed?	• Press the button once.  And check "[ -]" sign on the display.			
	Is there power cut while in cooking?	• Re-press the (************************************			
When the rice is not well cooked.	<ul> <li>Did you use the measuring cup to measure your rice?</li> <li>Did you measure proper water?</li> <li>Did you clean the rice before cooking?</li> <li>Did you put rice in water too long time?</li> <li>Is the rice old or dry?</li> </ul>	<ul> <li>Refer to page 11~12.</li> <li>Insert some more water (about half of 1 level)</li> </ul>			
Bean (other grains) is half cooked.	Is bean (other grains) is too dry?	Soaked or steam beans other grains before cooking in the pressure cooker in order to avoid partially cooked beans or grains. Beans should be soaked for-to- minutes or steamed for-to-minutes prior to cooking, depending on your taste.			
Rice is too watery or stiff.	<ul><li>Is it selected the menu correctly?</li><li>Did you measure proper water?</li><li>Did you open the top cover before cooking was finished?</li></ul>	<ul> <li>Select the correct menu.</li> <li>Measure the proper water.</li> <li>Open the top cover after cooking finished.</li> </ul>			
When the water overflow.	<ul><li>Did you use the measuring cup?</li><li>Did you measure proper water?</li><li>Is it selected the menu correctly?</li></ul>	Refer to page 11.			
When you smell something while warming.	<ul> <li>Did you close the top cover.</li> <li>Please check the power cord input to wall socket.</li> <li>Did it warm over 12 hours?</li> <li>Is there any other substance such as rice scoop or cold rice.</li> </ul>	<ul> <li>Close the top cover perfectly.</li> <li>Always be keeping the power on while warming.</li> <li>As possible as warming time is within 12 hours.</li> <li>Don't warm rice with other substance.</li> </ul>			
"E " sign is appeared.	There is some problem on the temperature sensor.	Please contact to dealer or service center.			
Did it not finished the cooking for a long time with "E []] ".	Check the rated voltage?	<ul> <li>120V only.</li> <li>If were any problem on the circuit, please contact dealer or service center.</li> <li>It is normal when inserted only water.</li> </ul>			
When the button cannot operate with " [] ".	Is there inner pot?	Please insert inner pot.			
When the button are not operate with "E []  "	<ul><li>Did you turn the Lock/Unlock Handle to "Lock"</li><li>Is "pressure" lamp on?</li></ul>	Please turn the Lock/Unlock Handle to  "Lock"			
When the rice is badly sticky.	<ul> <li>Is there any rice or any other alien substance on the temperature sensor, heating plate or the bottom surface of the inner pot?</li> </ul>	Clean all the alien substance on the temperature sensor, heating plate or the bottom surface of the inner pot.			

# CHECK BEFORE ASKING FOR SERVICE

Case	Check points	Do the following
When the time cannot be preset.	<ul><li>Is the current time correct?</li><li>Is it right AM or PM?</li><li>Did you set the reservation time over 13 hours?</li></ul>	<ul> <li>Set the current time. (Refer to page 10)</li> <li>Check the AM, PM.</li> <li>Maximum reservation time is 13 hours. (Refer to page 18)</li> </ul>
When you smell after and before cooking?	Did you clean it after cooking?	Please clean it after cooking.
When the top cover cannot be closed.	<ul> <li>Is the inner pot correctly put in the main body?</li> <li>Is the Lock/Unlock handle on the top cover set to "Lock"?</li> <li>Is there hot thing in the inner pot?</li> </ul>	<ul><li>Please put in the inner pot perfectly.</li><li>The Lock/Unlock handle to "Unlock".</li><li>Pull the pressure weight to aside once.</li></ul>
When cannot turn to "Unlock".	<ul> <li>Did you turn the Lock/Unlock handle while cooking?</li> <li>Did you turn the Lock/Unlock handle before exhausting steam perfectly?</li> </ul>	<ul> <li>Don't open the top cover while cooking. If you want to open top cover while cooking, press the button more than 2 seconds and exhaust the steam.</li> <li>Pull the pressure weight to aside once and exhaust the steam perfectly.</li> </ul>
When the top cover cannot open although the Lock/Unlock handle to "Unlock".		<ul> <li>Because of pressure.</li> <li>Pull the pressure weight to aside once and exhaust the steam perfectly.</li> </ul>
When "tick, tick" sounds occurs while cooking and warming.	<ul><li>Is it the sound of cooking relay?</li><li>Did you wipe the moisture of bottom of inner pot?</li></ul>	<ul> <li>It is normal that the "tick, tick" sound of relay is an on and off operation.</li> <li>The moisture of the bottom of the inner pot may cause "tick, tick" sound.</li> <li>Please wipe the moisture.</li> </ul>
When the steam exhausted between the top cover.	<ul><li>Is there alien substance on the packing?</li><li>Is packing too old?</li></ul>	<ul> <li>Clean the packing with duster.</li> <li>Keep to be clean near the packing.</li> <li>If the steam is exhausted the top cover, please power off and contact the service center and dealer.</li> <li>Packing life cycle is 12 month, please replace the packing per 1 year.</li> </ul>
When the button does not operated while cooking.	Is the inner pot hot?	<ul> <li>Keep pressing the cancel button for 2 seconds for safety reason if you like to cancel while cooking.</li> <li>Be carefully of hot steam emission or hot contents spattered from the automatic steam outlet when cancelation.</li> </ul>
Brown rice is not germinated properly	<ul> <li>Does the quantity of rice exceed the specified maximum capacity?</li> <li>Is the Brown rice too old?</li> </ul>	<ul> <li>Put the specified maximum capacity of Brown rice.</li> <li>Dried or contaminated rice may mot be germinated properly. (Refer to page 16)</li> </ul>

## 안전을 위한 주의사항

- ●'안전상의 경고'는 제품을 안전하고 올바르게 사용하여 사고나 위험을 미리 막기 위한 것이므로 반드시 지켜 주십시오.
- '안전상의 경고'는 '경고'와 '주의'의 두가지로 구분되어 있으며 '경고'와 '주의'의 의미는 다음과 같습니다.

⚠경고

피하지 않을 경우 사망이나 중상을 초래할 수 있는 잠재적인 위험상황

⚠ 주의 및 피하지 않을 경우 경상을 초래할 수 있는 잠재적인 위험상황

A

- •이 기호는 특정조건하에서 위험을 끼칠 우려가 있는 사항에 대하여 주의를 환기시키는 표시입니다. • 위험 발생을 피하기 위해 주의깊게 읽고 지시에 따라 사용하십시오.
- 이 기호는 어떤 행위를 '금지'하는 표시입니다.
- 이 기호는 어떤 행위를 '지시'하는 표시입니다.

# ⚠ 경고

제품에 직사광선이 쬐는 곳, 가스레인지, 전열기구 등의 가까이에서 사용하지 마십시오.

- ▶ 전기누전 및 감전 변형 및 변색의 원인이 됩니다.
- ▶ 전원코드를 열기구 가까이 두지 마십시오 코드피복이 녹아 화재, 감전의 원인이 됩니다.

씽크대, 목욕탕 등 제품에 물이 들어 갈 수 있는 곳이나 화학성 물질이 있는 곳에서는 사용하지 마십시오.

- ▶ 전기 누전 및 감전의 위험이 있습니다.
- ▶ 먼지가 많은 곳이나 화학성 물질이 있는 곳에서는 사용하지 마십시오.



어린이 혼자 사용하거나 어린이가 만질 수 있는 장소에 제품을 두지 미십시오

▶ 고열에 화상을 입거나 감전이 될 수 있습니다.



제품을 씽크대에 넣고 닦거나 제품 내부에 물을 넣지 마십시오.

- ▶ 전기 누전 및 감전 화재의 원인이 됩니다.
- ▶ 제품에 물이 들어간 경우에는 사용을 중지하고 전원플러그를 뽑은 다음 구입하신 대리점이나 서비스 센터로 문의해 주십시오

사용중 압력추 및 자동 증기 배출구에는 손과 얼굴을 가까이 하지 마십시오.

- ▶ 화상의 우려가 있습니다.
- ▶ 취사중 나오는 증기는 매우 뜨거우므로 손이나 얼굴을 가까이 하지 마십시오
- ▶ 특히 어린이의 접근을 막아 주십시오



전원플러그를 콘센트에서 꽂거나 뺄때는 손의 물기를 반드시 제거한 후 전원플러그를 잡고 꽂거나 빼어 주십시오.

- ▶ 젖은 손으로 전원플러그를 꽂거나 뽑으면 감전의 원인이 될 수 있습니다.
- ▶ 무리하게 당겨 뽑으면 전원코드에 이상이 발생되어 누전 및 감전이 될 수 있습니다.



반드시 정격 15A 이상의 교류 120V 전용 콘센트 에서만 사용해 주시고 한 콘센트에 여러 제품의 전원플러그를 동시에 꽂아 사용하지 마십시오.

- ▶ 여러 제품과 함께 사용하거나, 다른 기구에 사용하면 발열 및 발화 감전의 원인이 됩니다.
- ▶ 전원플러그에 이물질이나 물기가 묻어 있는 경우에는 잘 닦은 다음 사용하십시오.
- ▶ 연장코드도 15A이상의 것을 사용하여 주십시오.



전원코드나 전원플러그가 파손되었거나 콘센트가 흔들릴 때는 사용을 중지하고, 구입하신 대리점이나 서비스센터로 문의 바랍니다.

- ▶ 전원코드나 전원플러그가 파손된 경우에는 위험이 생기지 않도록 하기 위하여 제조자나 그 판매점 또는 유자격 기술자(서비스 기사)에 의해 코드 교환을 하십시오.
- ▶ 반드시 구입하신 대리점이나 서비스 센터에서 수리하시기 바랍니다.

0

# 1 경고

## 전원코드 위에 무거운 물건을 올려 놓거나 코드가 제품바닥에 눌러지지 않도록 주의해 주십시오.

▶ 화재 및 감전의 원인이 됩니다



온도감지기, 열판 및 내부 또는 내솥 주위의 이물질은 반드시 제거한 후에 사용하십시오.

▶ 온도감지를 정확히 못하게 되므로 내솥이 가열되어 이상작동 및 화재의 원인이 됩니다.



## 밥이 끓고 있을 때 절대로 뚜껑을 열지 마십시오.

구입하신 대리점이나 서비스 센터로 문의해 주십시오.

변형된 내솥이나 전용 내솥이 아닌것을 사용하거나,

- ▶ 밥이 끓고 있을 때는 압력에 의해 뚜껑이 열리지 않습니다. 강제로 열면 화상 및 폭발의 위험이 있습니다.
- ▶ 취시중 부득이 하게 뚜껑을 열어야 할 경우 취소 버튼을 누른 후 압력추를 젖혀 증기가 완전히 배출되었는지 확인을 하고 열어 주십시오

내솥 없이 사용을 하지 마십시오. 감전 및 고장의 원인이 됩니다.

내솥이 없는 상태에서 쌀이나 물을

내솥이 가열되어 이상작동 및 화재의

내솥을 떨어뜨렸거나 변형된 경우에는 제품을

넣지 마십시오.

원인이 됩니다.

## 제품을 분해하거나 개조하지 마십시오.

- 화재 및 감전의 원인이 됩니다.
- ▶ 서비스기사 이외의 사람이 분해하거나 수리하지 마십시오.
- ▶ 수리 및 고장 상담은 구입하신 대리점이나 서비스 센터로 문의해 주십시오.



## 제품 내부에 금속막대기등 이물질을 절대 넣지 마십시오. (특히, 어린이 주의)

▶ 감전 및 화재의 원인이 됩니다.

## 제품내에 살충제나 화학 물질등을 뿌리거나 투입하지 마십시오.

- 화재 발생의 우려가 있습니다.
- 제품내 바퀴벌레나 벌레등이 들어 갔을 경우에는 제품을 구입하신 대리점이나 서비스 센터로 문의해 주십시오




## 흡·배기구 또는 틈 사이에 바늘, 청소용 핀 금속물 등 이물질이 들어가거나 막히지 않도록 하십시오


- 청소용 핀을 증기배출구 청소 외에 제품의 틈새나 다른 구멍에 넣지 마십시오.
- ▶ 감전 및 제품 고장의 원인이 됩니다.
- ▶ 특히, 어린이는 주의 시켜 주십시오.

## 제품 밑에 깔판, 방석, 전기 장판 등을 놓고 사용하거나, 경시진 곳이나 울퉁불퉁한 곳에서는 사용하지 마십시오.


- ▶ 화재 및 변형의 원인이 됩니다.
- ▶ 화상 및 제품 고장의 원인이 됩니다.
- ▶ 전원코드에 손이나 발, 기타 물체가 걸려 제품이 떨어지지 않도록 주의 하십시오




- ▶ 강제로 열 경우 압력으로 인해 화상 및 폭발의 위험이 있습니다.
- ▶ 취사 완료 후 증기가 완전히 배출된 상태에서 뚜껑 결합 손잡이를 작동시키십시오.




- ▶ 본체의 변형, 변색 및 고장의 원인이 됩니다.
  - ▶ 압력에 의한 폭발의 위험이 있습니다.



- 전원코드가 틈새에 눌러져 화재 및 감전의 원인이 됩니다.
- ▶ 취사 중 증기가 배출될 때 쌀통 및 다용도 선반에 의해 제품의 손상, 화재, 감전의 원인이 됩니다.



O



▶ 감전이나 쇼트로 인해 화재의 원인이 될 수 있습니다.

## 전원 플러그에 묻은 이물질은 천으로 제거하여 주십시오.

▶ 화재의 원인이 됩니다.





# ↑ 주의

## 사용 중이거나 사용직후에는 내솥, 내부, 열판 및 압력추 등은 뜨거우므로 만지지 마십시오.

- ▶ 고열에 의해 화상을 입을 수 있습니다.
- ▶ 내솥은 손잡이를 잡고 사용하십시오.
- ▶ 압력추가 젖혀져 증기에 의해 화상을 입을 수 있습니다.



## 최대 용량 이상으로 내용물을 넣고 사용하지 미십시오.

▶ 밥물 넘침이나 취사 불량 등 고장의 원인이 됩니다.



## 내솥 손잡이를 잡고 제품을 들어 올리지 마십시오.

▶ 내솥 손잡이를 잡고 들어 올릴 경우 뚜껑이 열려 위험합니다. 제품 밑바닥 좌우측에 이동용 손잡이 홈이 있습니다. 홈을 양손으로 들어올려 안전하게 사용하십시오.





## 취사 완료 후 또는 보온시 뚜껑 결합 손잡이가 잘 돌려지지 않을 때 강제로 돌리지 마십시오.

- ▶ 화상 및 제품손상의 원인이 됩니다.
- ▶ 압력추를 젖혀 증기가 왼전히 배출되었는지 확인 후 뚜껑결합손잡이를 돌려주십시오
- ▶ 취사 완료후 뚜껑을 열때 증기에 의한 화상의 우려가 있으므로 주의 하십시오



()

## 취사 완료 후 자동증기 배출시 주의하십시오.

- ► 증기가 고속으로 배출되면서 '취익'하는 소리가 나므로 놀라지 않도록 주의 하십시오.
- ▶ 특히, 어린이의 접근을 막아 주십시오 화상의 원인이 됩니다.



## 자성이 강한 물체 근처에서 사용하지 마십시오. 제품에 심한 충격을 주거나 떨어뜨리지 마십시오.

- ▶ 제품 고장 및 기능이 정상적으로 작동되지 않을 수 있습니다.
- ▶ 제품 고장 및 안전상의 문제가 발생할 수 있습니다.



## 내솥을 다른 용도로 사용하거나 불위에 올리지 마십시오.

▶ 내솥의 변형 및 코팅이 벗겨져 제품에 이상이 발생할 수 있습니다.



## 사용하지 않을 때는 전원플러그를 콘센트에서 뽑아 주십시오

- ▶ 감전, 화재의 원인이 될 수 있습니다.
- ▶ 제품이 정상적으로 작동을 하지 않습니다.

## 내솥 코팅이 벗겨질경우 고객상담실로 문의해주십시오 교투

- ▶ 제품을 장기간 사용 할 경우 내솥 코팅이 벗겨질수 있습니다.
- ▶ 내솥을 씻을 때는 41쪽을 참조 하십시오.

## 교류 120V 이외에는 사용하지 마십시오.

▶ 절연열화로 인해 감전, 누전, 화재의 원인이 될 수 있습니다.

## 취사가 끝난 뒤에는 반드시 본체에 고인물을 닦아 주십시오 요리 후에는 반드시 청소해 주십시오

- ▶ 이상한 냄새 및 변색의 원인이 됩니다.
- ▶ 본체의 물받이에 고인물은 닦아주십시오.
- ▶ 만능찜 등의 요리 후 취사 및 보온을 하게 되면 밥에 냄새가 배어들 수도 있습니다. 41쪽을 참조하여 내솥. 내솥뚜껑, 패킹 등을 깨끗이 닦아낸 후 사용하십시오
- 내솥뚜껑 세척 시 거친 수세미나 금속성 수세미를 사용할 경우 코팅이 벗 겨질 수 있으니 반드시 스폰지 또는 물기를 제거한 행주로 닦아주십시오.
- 제품의 사용환경이나 방법에 따라 내솥뚜껑의 코팅이 벗겨질 수 있습니다. 이런경우 고객상담실로 문의해 주십시오.

## 전원플러그를 뽑더라도 뚜껑 결합 손잡이를 항상 "Lock"위치로 돌려 주십시오.

- ▶ 취사완료후 내솥이 뜨겁거나 뜨거운 밥이 남아 있을 경우 전원플러그를 뽑더라도 뚜껑을 닫고 뚜껑 결합 손잡이를 "Lock" 위치로 돌리지 않으면 내부압력에 의해 제품의 변형이나 손상의 원인이 됩니다.
- ▶ 손잡이를 "Lock" 위치에 놓고 사용해 주십시오.

## 취사, 보온, 지정된 메뉴 이외의 물끓임, 식혜, 미역국, 카레, 기름으로 튀기는 요리 등 다른 용도로 사용하지 마십시오.

▶ 고장 및 냄새의 원인이 됩니다.



사용 중에 이상한 소리나 냄새 또는 연기가 나면 즉시 전원플러그를 뽑고 압력추를 젖혀 내부 압력을 완전히 제거하신후 구입하신 대리점이나 서비스 센터로 문의 하십시오.

# 사용상의 주의사항

## 뚜껑을 강제로 닫지 마십시오. 고장의 원인이 됩니다.



## ▶ 뚜껑을 열고 닫을 때

- 1. 내솥의 손잡이를 본체의 양쪽홈에 맞도록 놓아주십시오. (아래 그림 참조)
- 2. 손잡이 위치를 "Unlock" 위치로 맞춘 다음 열고 닫아 주십시오.




## ▶ 취사/보온시

- 취사/보온 중에는 손잡이 위치를 "Lock" 위치에 맞춰 주십시오.
  - \*\* 밥솥 내의 압력이 차면 손잡이가 돌아가지 않습니다. 이때 압력추를 젖혀 증기를 빼 주십시오.
- ●청소를 잘하지 않으면 보온 중 냄새가 나는 원인이 됩니다. 특히 뚜껑부는 자주 청소해 주십시오. (전원 플러그를 뽑고 본체의 열이 식고 난 후 손질 하십시오)
- ●고무패킹이나 내솥 안쪽면 상단부에 밥알 등 이물질이 묻어 있으면 증기가 누설되어 밥이 설익고, 퍼석해 집니다.

뚜껑 내면은 물을 꼭 짠 행주로 닦아 주십시오

본체에 고인 물을 꼭 짠 행주로 닦아 주십시오

온도 센서에 이물질이 붙어 있는 경우는 금속판이 손상되지 않게 제거하세요



······· 고무패킹에 밥알 등 이물질이 소 문어 있는지 확인합니다.

> 사용전 • 후 증기배출구가 막히지 않도록 깨끗이 닦아 주십시오.

뚜껑의 가장자리 부분은 금속으로 되어 있으므로 청소할때 주의하십시오.
 내솥 안쪽면 상단부 및 바깥면의 이물질이나 물기를 깨끗이 닦아 주십시오.

▶ 내솥(OVEN)을 다른 용도로 사용하거나 가스/전기 오븐등의 불위에 올리지마십시오. 내솥의 변형 및 코팅이 벗겨져 제품에 이상이 생길 수 있습니다.

## 압력추 부분의 밸브 구멍이 이물질 등으로 막혔을 때 청소용 핀으로 뚫어 주십시오.


- 압력추 부분의 밸브 구멍이 이물질 등으로 막혀있는지 정기적으로 점검하십시오. 밸브 구멍이 막힌 상태로 사용하시면 내솥에서 뜨거운 증기와 내용물이 튀어 나와 회상, 부상의 원인이 됩니다.
- ※ 청소용 핀으로 압력추 증기 배출구만 청소하시고, 다른 구멍은 안전장치이므로 절대로 찌르지 마십시오.



## 압력추 분리 방법

- ▶ 뚜껑 결합 손잡이가 잠긴 상태("Lock"위치)에서 압력추를 잡고 위로 들면서 화살표 방향 (반 시계 방향)으로 돌려서 분리합니다.
- ▶ 청소용 핀으로 구멍을 뚫고 체결 할 때는 다시 압력추를 반대방향으로 돌려서 끼워 넣습니다.
- ▶ 압력추가 완전히 체결되면 추가 자유롭게 돌아갑니다.

# 각 부분의 이름



취사전 압력추를 수평으로 맞추어 주십시오. 내부의 압력이 일정하도록 조절하며, 젖히면 수동으로 증기배출이 됩니다.

### 소프트스팀캡

### 자동 증기 배출구

취사가 끝나거나 보온시 자동으로 증기를 배출시켜 줍니다. (필요한 경우 취소버튼을 눌러 (2초)증기를 배출 시킬 수도 있습니다.)

· • 뚜껑 결합 손잡이 취사시 손잡이 표시 (🔰 )가 "Lœk" 위치로 되어야 작동이 됩니다.

## 소프트스팀캡 손질 방법

1. 소프트스팀캡을 그림과 같이 떼어냅니다.




2. 뒷면에 있는 후크를 화살표 방향으로 눌러서 분해하고, 주방용 중성세제 및 스폰지로 자주 세척해 주십시오




3. 소프트스팀캡을 조립하여 끼울 때에는 \_\_\_ 앞쪽의 홈 부분을 맞춘 후, 회살표 방향으로 눌러 확실히 끼워주십시오



4. 제품에 소프트스팀캡을 장착할 때는 뚜껑부의 가이드 돌기 사이에 소프트스팀캡을 안착한 후 A부를 눌러 단단히 고정시켜 주십시오 가이드 돌기



※ 취사 직후에는 소프트스팀캡이 뜨거우므로 만지지 마십시오. 화상을 입을 수 있으므로 주의하십시오.



## 부속품 안내



사용설명서



주걱



요리안내



찍판



계량컵

청소용 핀 ※ 본체 바닥부에 있습니다.



메뉴 실

# 기능 조작부 설명

## 압력 램프

뚜껑 결합손잡이를 "Lock" 쪽으로 잠그면 불이 켜집니다.

## 음성안내 기능

Cancel 버튼을 2초간 누르면 음성안내 기능이 설정 및 해제 상태로 전환됩니다. 음성안내 기능이 설정된 상태일 때 "VOICE"가 표시됩니다.

## 백미쾌속램프


백미쾌속취사를 선택했을 때 불이 들어 옵니다.

## 보온/ 재가열 버튼

보온을 할 경우나 식사 직전 밥을 따뜻하게 데울 경우 ▶39, 40쪽 참조

## 예약버튼

예약취사를 할 경우 사용 ▶37, 38쪽 참조



## 압력취사/ 백미쾌속 버튼

취사 및 요리를 시작 할 경우 사용 ▶32, 33쪽 참조

## 취소버튼

●선택한 기능을 취소 할 경우 사용하거나 자동으로 증기를 배출시킬때 사용 ▶43쪽 참조

## 표시 창

- •취사시:초기에는 "[-]" 표시가 빙글빙글 돌다가 뜸들이기 시에는 남은 시간이 분단위로 감소되면서 표시됩니다.
- ●보온시:보온 경과 시간이 1시간 단위로 증가되면서 표시됩니다.
- ●예약시:예약 밥짓기 완료시간이 표시됩니다.

## 시/분/맞춤밥맛 버튼

- ●현재 시각을 맞추거나 예약 시각을 변경 할 경우 사용 ▶29쪽 참조
- '쿠쿠 맞춤밥맛' 기능을 설정할 경우 사용 ▶34쪽 참조

## 메뉴 버튼

- ●백미, 김초밥, 잡곡, 현미발아, 묵은쌀, 누룽지, 고구마, 만능찜 등의 메뉴를 선택할 경우 사용 ▶33쪽 참조
- ●보온 강약 조절기능을 사용할 경우 사용 ▶39쪽 참조

## 현재 시각 맞추는 방법

1 전원 플러그를 꽂습니다.



2. Hrs 또는 Min

버튼을 1초이상 눌러주십시오.



3. Hrs , Min 버튼으로 현재 시각을 맞춥니다

현재 시각을 맞춥니다. 이때 버튼은 1초이상 눌러 주십시오.



4. 7초 후 변경된 시각으로 자동 입력됩니다.

참

 $\mathbf{7}$ 

- ▶ Hrs, Min 버튼으로 현재 시각을 맞춘 뒤, Hrs, Min 및 Cancel 버튼을 제외한 다른 버튼을 눌러도 현재 시각으로 설정됩니다.
- ▶ 현재 시각이 틀린 상태에서 예약을 하면 예약 밥짓기 완료시간이 맞지 않게 됩니다.
- ▶ 보온중 일 때 현재 시각을 맞출 때는 <sup>(জুল)</sup> 버튼을 누른 후 시작 하십시오. 현재시각 설정이 끝나면 <sup>(জুল)</sup> 버튼을 1회 눌러 보온합니다. 이때 표시부에는 "**[卅**"가 표시됩니다.

⚠ 경고

본 제품에는 정전보상기능 및 시계기능을 위하여 리듐전지가 내장되어 있으며 수명은 약 3년입니다. 단, 사용 상태에 따라 차이가 날 수 있습니다. 불에 넣거나 열이 나는 곳에 가까이 방치, 쇼트, 분해나 충전은 절대 하지 마십시오.

# 쌀을 깨끗이 씻어서.....

## 계량컵으로 쌀을 인분수 만큼 정확하게 담아서 씻어주십시오.

※ 한컵은 1인분에 해당됩니다.

## ▶쌀을 담는 바른 방법







맑은 물이 나올때까지 깨끗이 씻으시면 밥맛이 더욱 좋습니다. (별도 용기 사용)

# 2 물을 정확히 맞추고.....


내솥에 깨끗이 씻은 쌀을 넣고 물의 양을 물(水)높이 눈금에 맞추어 주십시오. ※내솥을 평평한 곳에 놓고 물의 양을 맞추십시오.

● 8인분 제품일때 (FA08 Series)

진밥을 원할 때 : 물을 규정량보다 많이 부어 주십시오.

- ·쌀 6인분의 경우 (계량컵 6컵) 내솥의 백미 눈금 ⑥에 물을 맞춥니다.
- ·쌀 4인분의 경우 (계량컵 4컵) 내솥의 백미 눈금 (4)에 물을 맞춥니다.

쌀을 충분히 불렸을 때 또는 된밥을 원할 때 : 물을 규정량보다 적게 부어주십시오. ● 6인분 제품일때 (FA06 Series)



## ※물 높이 조절에 대하여

- 8인분 제품일때(FA08 Series)
- ▶ 백미(Glutinous), 잡곡(Mixed), 누룽지(Nu Rung Ji) : '백미'물눈금 기준으로 물을 맞춥니다. 백미는 최대 8인분 잡곡, 누룽지는 최대 6인분까지 조리 기능합니다.
- ▶ 김초밥(Normal), 현미발(N(GABA), 묵은쌀(Dried) : '김초밥 현미발(N)' 물눈금 기준으로 맞춥니다 김초밥, 현미발(N), 묵은쌀은 최대 6위분까지 주리 기능합니다.
- 6인분 제품일때(FA06 Series)
- ▶ 백미(Glutinous), 잡곡(Mixed), 누룽지(Nu Rung Ji) : '백미' 물눈금 기준으로 물을 맞춥니다. 백미는 최대 6인분, 잡곡, 누룽지는 최대 4인분까지 '조리 기능합니다.
- ▶ 김초밥(Normal), 현미발아(GABA), 묵은쌀(Dried) : '김초밥 현미발아' 물눈금 기준으로 맞춥니다. 김초밥 현미발아, 묵은쌀은 최대 4인분까지 조리 기능합니다.


## 쌀 보관 방법

- ●쌀은 그늘지고 서늘한 곳에 보관하여 주십시오.
- ●쌀이 마르면 밥맛이 떨어지고 보온시 냄새가 나는 원인이 됩니다.
- ※ 쌀 보관시 피해야 할 장소 : 보일러 배관이 지나가는 뜨거운 곳 / 햇볕이 드는 곳 / 습기가 많은 곳
- ※ 쌀은 장시간 보관하면 품질이 떨어지므로 소포장 단위로 구입하여 사용하시면 좋습니다.

# 🐧 물기를 닦고 내솥를 넣은 다음.....

## 내솥 바깥면의 물기를 마른 행주로 닦아 본체에 넣은 다음 전원 플러그를 꽂아주십시오.

- ▶ 내솥이 본체에 정확하게 들어가지 않으면 뚜껑이 닫히지 않습니다.(내솥의 손잡이가 본체의 홈에 들어가도록 하십시오.)
- ▶ 온도 센서나 내솥의 바닥면에 쌀등의 이물질이 묻어 있으면 반드시 제거한 후에 내솥을 넣어 주십시오
- ▶ 취사 전 뚜껑 히터부를 행주로 깨끗하게 닦아 주십시오. 뚜껑 히터부가 깨끗하지 않으면 냄새 및 변색의 원인이 됩니다.
- ▶ 고무패킹과 내솥 안쪽면 상단부에 밥알 등 이물질이 묻어 있으면 증기가 누설되어 밥이 설익고 퍼석해 집니다.



# 4 뚜껑을 닫고 손잡이를 "Lock"위치로 돌려 주십시오.

## "Pressure" 램프에 불이 들어왔는지 확인하십시오. 압력추가 수평인지 확인하십시오.

- ▶ 뚜껑결합 손잡이를 "Lock"으로 맞추지 않고 취사 버튼을 누르면 경고음과 함께 표시창에 "[ □ | | | "이 나타나면서 작동이 되지 않습니다.
- ▶ 뚜껑을 닫을 때 내부 압력에 의해 잘 닫히지 않을 경우에는 압력추를 젖혀 증기를 완전히 빼 주시면 잘 닫힙니다.



# 기능 표시부의 이상점검 기능

- ▶ 사용방법이 올바르지 않거나 제품에 이상이 생겼을 때 아래와 같이 표시가 나타나 경보를 하여 줍니다.
  - LJ
- ▶ 내솥이 없거나 내부가 과열되었을 때 나타납니다.
- E \_ \_
- 온도 감지기에 이상이 있을 때 나타납니다.
   ("--"표시가 깜빡거립니다.)→ 구입하신 대리점이나 서비스 센터로 문의하십시오
- E [] |
- ▶ 뚜껑 결합손잡이를 확실하게 돌리지 않은 상태에서 ( ) 바른을 눌렀을때 나타납니다. 뚜껑 결합손잡이를 "Lock"쪽으로 확실하게 돌려 주십시오 이 때, "Pressure"램프에 불이 켜집니다.
- E 03
- 물만 계속 끓일 경우나 제품이상 발생시 나타납니다.→구입하신 대리점이나 서비스 센터로 문의하십시오
- 13 40
- ▶ 예약 시간이 13시간을 초과한 경우에 나타납니다. 13시간 이내로 예약을 하십시오.(37, 38쪽 참조)

# 취사 방법

## 백미 밥짓기

에 비른을 눌러 원하는 메뉴를 선택합니다.



2 (PRINTED 보기 보기 등을 눌러 주십시오.




- ▶ 취사전 압력추를 수평으로 맞추어 주십시오
- ▶ 메뉴는 모든 기능이 취소된 상태에서만 선택할 수 있습니다.

선택일 구 있습니다.

Menu 버튼이 작동되지 않으면 Cancel 버튼을

누른 후 Menu 버튼을 누르십시오.


▶ Menu 버튼을 누를 때마다 메뉴는 아래와 같이 계속 반복 선택됩니다.



- ▶ 취사를 하기전에 반드시 뚜껑 결합 손잡이를 "Lock"쪽으로 맞추고 ™ 버튼을 눌러 주십시오.
- ▶ 취사가 시작되면 "【\_\_\_]" 표시가 시계 방향으로 회전합니다.

(뱃 버튼을 누르면 공정율(%)이 표시되고,

- Min 버튼을 누르면 "[]"표시가 회전합니다.)
- ※ 공정율은 밥을 짓기위한 각 공정단계에 대한 표시이며, 취사시간에 대한 비율을 의미하지 않습니다.
- ► 뜸들이기가 시작되면 표시부에 취사 완료까지 남은 시간이 분단위로 감소하면서 표시됩니다.



- 3 밥짓기가 끝나면 밥을 골고루 잘 섞어 주십시오.
- ▶ 밥짓기 중에는 압력추로 증기가 빠지면서 압력이 자동 조절됩니다.
- ► 뜸 완료 3분전에 증기가 자동으로 배출됩니다. 김초밥 취시를 하실 경우는 취사중 1회, 뜸 완료 3분전 1회 증기가 배출됩니다. (놀램, 화상주의)
- ▶ 증기 배출 후 취사완료음이 울리고 보온으로 전환됩니다.
- ▶ 보온으로 전환되면 뚜껑을 열고 밥을 골고루 잘 섞어 주시면 보온이 오래갑니다.
- 취사 중에 정전이 되면 정전된 시간만큼 취사 시간이 늦어지며 정전시간이 오래되면 밥상태가 나빠집니다.
- ▶ 뚜껑결합 손잡이가 "Unlock" 위치로 잘 돌아가지 않는 경우에는 압력추를 젖혀 증기를 완전히 빼낸 후 뚜껑결합 손잡이를 돌려주십시오.



# 메뉴

- Glutin ous(백 미): 백미를 찰지게 취사할 때 사용합니다.
- Normal(김초밥): 일반밥솥과 찰진 압력밥솥의 중간밥을 드시고자 할때 사용합니다.
- Mixed(잡 곡): 백미에 곡류를 섞어서 취사할 경우 사용합니다.
- GABA(현미발아): 현미쌀을 발아하여 발아현미밥을 만들어 줍니다.
- Dried(묵은쌀):묵은쌀을 취사할 때 사용합니다.
- 오래 보관한 쌀 또는 수분이 줄어든 마른 쌀로 지으면 밥이 퍼석하거나 설익을 수 있습니다.
- 추수후 1년이상 경과되었거나, 개봉후 보관과정에서 쌀의 수분이 줄어든 마른 쌀의 경우는 묵은쌀 코스로 취사를 하시면, 더 좋은 밥맛을 얻을 수 있습니다.

(쌀의 보관 및 수분 상태에 따라서 멜라노이징 현상이 나타날 수도 있습니다.)

- ▶ 쌀 세척시 맑은물이 나올때 까지 깨끗이 세척하여 주십시오.
- ▶ 쌀은 장시간 보관하면 품질이 떨어지므로 소포장 단위로 구입하여 사용하시면 좋습니다.
- ▶ 쌀이 마르면 밥맛이 떨어지고 보온시 냄새가 나는 원인이 됩니다.
- Nu Rung Ji(누룽지): 취사할 때 누룽지를 만들어 줍니다.
- 누룽지가 완료되면 뚜껑을 열고 밥은 덜어내 드시고, 바닥의 누룽지는 기호에 따라 그냥 드시거나 숭늉을 만들어 드시면 됩니다.
- ▶ 누룽지 취사는 8인분 제품일때 최대 6인분까지,6인분 제품일때 최대 4인분까지만 가능합니다.
- ▶ 누룽지 취사시 물량은 "백미"물눈금 기준으로 맞추시면 됩니다.
- Sweet pot.(고구마): 찜판을 이용하여 고구마를 삶는 기능입니다.
- Multi Cook( 만능찜): 수동으로 찜시간을 설정해서 요리를 합니다.
- -만능찜 메뉴가 선택되었을 때는 기능표시부에 기본시간 20분이 표시됩니다.
- -만능찜 설정가능 시간은 10분에서 90분까지 입니다.
- 🖙 버튼을 누를 때 마다 만능찜 시간이 5분씩 증가함니다.
- 🐚 버튼을 누를 때 마다 만능찜 시간이 5분씩 감소합니다.
- -만능찜 시간선택 후 🚟 버튼을 누르면 만능찜 취사가 시작됩니다.
- 😘 버튼을 누르면 잔여시간이 표시되고. 🐚 버튼을 누르면 [\_\_]를 회전시켜 취반진행을 표시합니다.
- ※ 참조 메뉴별 상세한 요리방법은 "요리안내"를 참조 하십시오

## 메뉴별 취사시간

구분	메뉴	Glutinous (백미)	Turbo Guifn cus rice(백미쾌속)	Normal (김초밥)	Mixed (잡곡)	GABA (현미발아)	Dried (묵은쌜)	Nu Rung Ji (누룽지)	Sweet Pot. (고구마)	Multi Cook (만들쬬)
6인분	취 사 량	2인분~ 6인분			2인분	~4인분			3개 (150g이하)	
제품	취사시간	약28분~ 약36분	약18분~ 약24분	약32분~ 약39분	약46분~ 약49분	약48분~ 약52분	약38분~ 약42분	약37분~ 약42분	약32분	메뉴별 상세 요리안내를
8인분	취 사 량	2인분~ 8인분			2인분	~6인분			4개 (150g이하)	참조하여 주십시 <b>오</b> .
제품	취사시간	약31분~ 약37분	약18분~ 약27분	약32분~ 약43분	약46분~ 약53분	약48분~ 약57분	약38분~ 약43분	약37분~ 약44분	약34분	

※ 고구마를 삶을 때 무게가 150g 이상인 것(큰것)은 반드시 잘라서 요리해 주십시오 만능찜 등의 요리 후 취사하게 되면 냄새가 배어들 수도 있습니다. 27, 41쪽을 참조하여 패킹과 뚜껑 부위를 깨끗이 닦아 낸 후 사용하여 주십시오.

## 백미쾌속기능

- ▶ "GLUTIONUS(백미)" 메뉴를 선택한 후 ₩ 버튼을 두번 누르면백미쾌속 취사로 동작 하여밥짓는 시간이 단축됩니다. (백미 2인분 기준 약18분 정도걸림)
- ▶백미쾌속 취사는 8인분 제품 일때 최대 6인분까지, 6인분 제품일때 최대 4인분까지만 가 능합니다.
- ▶취사전 쌀을 20분 정도 불린 다음 백미 쾌속으로 취사하면 밥맛이 좋아집니다
- ▶백미쾌속 취사는 예약이 되지 않습니다.

# '쿠쿠 맞춤밥맛' 사용 방법

## '쿠쿠 맞춤밥맛'이란

▶ 세계 최초로 쿠쿠만의 가변회로 기술을 개발하여 밥의 "부드러운 정도"와 "차지고 구수한 정도"를 자신의 기호에 맞게 선택하여 취사하는 기능으로 소비자가 원하는 밥맛으로 취사할 수 있는 쿠쿠만의 특허 기술입니다.

## '쿠쿠 맞춤밥맛'기능


- ▶ "SOAK(불림시간)"을 길게 선택하면 : 밥맛이 부드러워지고 찰기가 많이집니다.(불림시간 4단계 선택가능)
- ▶ "HEAT(가열유지시간)"을 길게 선택하면 : 밥맛은 더 구수해집니다.(가열유지시간 4단계 선택가능)

(멜라노이징이 발생 할 수 있습니다.)

※ 기호에 따라 불림시간, 가열유지시간을 각각 선택하셔도 되고 두 기능을 동시에 선택하셔도 됩니다.

## '쿠쿠 맞춤밥맛'사용 방법

- ▶ 맞춤밥맛 시간을 변경하고자 하는 메뉴를 선택한 상태에서 ₩ 버튼을 누르면 그림과 같이 "SOAK(불림시간)" 조정모드가 나타납니다.
- ▶ '쿠쿠 맞춤밥맛'기능은 백미(Glutinous), 잡곡(Mixed), 현미발아(GABA), 묵은쌀(Dried) 메뉴에 적용됩니다. ☞백미, 잡곡, 현미발아, 묵은쌀 이외에 메뉴가 선택된 상태에는 버튼이 입력되지 않습니다.



\* 한 번 설정된 선택시간은 다시 변경하기 전까지 계속 기억되므로, 매번 취사시마다 시간을 맞출 필요가 없습니다. 취사 및 보온, 예약취사가 진행 중에는 불림시간, 가열유지시간을 조정할 수 없습니다.

## 주의사항

- 1. '쿠쿠 맞춤밥맛' 기능을 사용시 눌음현상 발생과 취반상태 등에 영향을 줄 수 있습니다. 어린이의 조작 등으로 인해 시간이 임의로 변경되지 않도록 주의하여 주십시오. \*\*초기 설정치는 불림시간(SOAK) 0분, 가열유지시간(HEAT) 0분으로 설정되어 있습니다.
- 2. '쿠쿠 맞춤밥맛' 기능을 사용하게 되면 설정된 시간만큼 취사시간이 다소 길어질 수 있습니다.
- 3. 가열유지시간(HEAT)을 길게 설정하면, 눌음현상이 나타날 수 있습니다.


# 현미발아 취사 방법


## 발아현미란

▶ 현미는 백미에 비교해 영양가가 높은 식품입니다. 하지만 먹었을 때 거칠고 딱딱하며, 소화하기 힘들다는 단점을 가지고 있습니다. 그러나 아주 조금만 발아시켜도 잠자고 있던 효소가 활성화되어 영양성분이 보다 풍부하게 되고 소화 흡수가 훨씬 수월한 형태로 변화됩니다.

## 현미 구입방법

- ① 먼저 생산일자와 도정일자를 확인 하십시오.
- ▶ 수확한지 1년 이내 그리고 도정일자로부터 3개월 이내의 현미를 사용하십시오.





(불량현미 - 쭉정이와 덜 여문현미)


## ❷ 눈으로 현미를 직접 확인하십시오

- 씨눈이 살아 있는지 먼저 확인하십시오.
- 쌀 표면이 밝은 황색을 띄고 표면에 윤기가 흐르면 좋은 현미이고 표면이 하얗게 일어나거나 색이 검은 기운을 띄면 발아에 적합하지 않은 현미 입니다.
- 조각나거나 덜 여문 현미는 피하시고 쭉정이가 없는 현미를 고르세요 쭉정이는 발아 중 썩어 냄새를 유발하고 푸르스름한 색을 띄는 덜 여문 현미는 발아가 되지 않습니다.

## 발아현미의 특징

발이현미는 영양가 높은 현미를 발아 시켜 영양소를 더욱 증가시키고 현미의 단점인 거친 반맛이 개선된 소화가 잘되는 훌륭한 영양원입니다.

- ▶ 현미보다 부드러운 밥맛을 즐기실 수 있습니다.
- ▶ 소화가 잘되고 영양소가 풍부합니다.
  - 발아과정에서 당화호르몬이 분비되어 소화흡수가 잘 됩니다.
- ▶ 어린이나 수험생의 영양 건강식으로 좋습니다.
  - 식이섬유가 풍부합니다.
- ▶ 발0현미에는 GABA(감마 아미노 낙산)가 다량 함유되어 있습니다.
  - GABA는 간장이나 신장의 신진대사를 촉진하며 중성지방 증가 억제 작용, 혈압상승 방지효과, 뇌세포 대사 촉진 등 우리 몸에 좋은 효과가 있음이 의학적으로 확인되었습니다.



분석예(일본 식품분석 센터에 의한 분석예)

< 발아현미(6시간)와 백미의 영양 비교 >

발0현미는 백미에 비해 높은 영양소를 가집니다.


- ▶ 피틴산 10.3배
- ▶ 페롤릭산 1.4배
- ▶ 감마오리자놀 23.9배
- ▶ 감마아마노낙산 5배
- ▶ 이노시톨 10배
- ▶ 식이섬유 4.3배

# 현미발아 취사 방법

▮ 발아를 더욱 촉진 시키기 위해 현미를 미리 16시간 이내로 침수하여 예비발이를 해주십시오.

## 예비발아방법

- ▶ 일반적으로 가정에서 사용하시는 용기에 씻은 현미를 넣은 뒤,최대한 물을 충분히 넣고 예비발아하여 주십시오
- ▶ 예비발아는 16시간 이내로 하여 주시고 현미발아 메뉴 사용 전에는 반드시 흐르는 물에 세척하신 후 사용하여 주십시오. 지나치게 세게 문질러 세척하면 쌀눈(배아)이 떨어져 발아되지 않을 수 있습니다.
- ▶ 예비발아하실 때 침수시간에 따라 특유의 냄새가 날 수 있습니다.
- ▶ 예비발아가 완료된 현미는 씻은 후에 내솥에 넣고 취사량에 따라 물높이를 맞추신 후 현미발아 메뉴를 사용하여 주십시오.
- ▶ 기온이 높은 여름이나 보관온도 등에 따라 예비발아시에는 냄새가 날 수 있으니 가급적 보관기간을 줄여 주시고 더 주의해서 깨끗이 잘 씻어 주십시오.
- 2 뚜껑 걸합 손잡이를 "LOCK" 위치에 맞추고, Menu 비튼을 눌러 "GABA"를 선택합니다.




▶ 현미발아(GABA) 메뉴가 선택되었을 때는 표시부에 2H가 표시됩니다.

# 3 Hrs Min 버튼을 둘러 사단을 살챙합니다.

- ▶ this 버튼을 누르면 현미발아 시간이 2시간씩 증가합니다.
- ▶ ∰ 버튼을 누르면 현미발아 시간이 2시간씩 감소합니다.
- ▶ 현미 발아시간은 0, 2, 4, 6 시간 으로 설정 가능합니다.
- ☞ 현미발아 '0'시간으로 설정 후 □ 변화 버튼 입력시 즉시 취사가 진행됩니다.

현미를 발아시키지 않고 취반할 경우 또는 이미 발아가 되어있는 현미로 취반할 경우에는 '0'시간으로 설정하십시오.

# Properties Control of Control of



- ※ 발아잔여시 간이 3시간남아있을 때
- ▶ 현미 발아중에는 "COOK"표시가 나타나며 남은 시간이 표시됩니다.

## 현미발아 취사시 유의사항 (현미발아는 예약취사 기능이 없습니다.)

- ▶ 발아된 싹의 크기를 키우지 않고 좀 더 빨리 드시고 싶으면 예비발아를 하지않고 현미발아를 선택하여 원하는 발아시간을 설정하신 후 취사버튼을 눌러 취사하십시오 (싹의 크기에 따라 영양분의 차이는 크지 않습니다.)
- ▶ 기온이 높을때 오랜시간 발아시키면 냄새가 날 경우가 있습니다. 그 경우에는 발아 설정시간을 단축하여 짧게 설정하여 주십시오.
- ▶ 현미발아 메뉴로 취사하실 경우에는 8인분 제품은 최대 6인분, 6인분 제품은 최대 4인분 이하로 하여 주십시오.
- ▶ 물은 수돗물을 사용하셔도 무방하나 생수를 이용하시면 더욱 좋습니다.단, 뜨거운물, 끓인물은 식힌 경우라 하더라도 발아가 되지 않을수 있으니 사용을 피해주십시오
- ▶ 현미의 발아율이나 싹의 길이 등의 발아상태는 현미의 종자와 보관상태, 보관기간에 따라 차이가 있을 수 있습니다.
  - 발아현미는 현미를 싹틔운 것으로 현미의 종자에 따라 발아율 및 발아된 후의 싹의 길이에 차이가 있을 수 있습니다. 발아시킬 현미는 반드시 수확후 1년 미만의 것을 사용해 주시고, 도정후 보관기간이 가급적 짧은 것을 이용해 주십시오.

# 예약 취사 방법

- 쌀을 씻어 내솥에 담아 물을 맞추어 취사준비를 먼저 한 후 뚜껑결합 손잡이를 "Lock"으로 돌려주십시오.
- 예약시각은 취사가 완료되는 시간입니다. (취사량 및 사용조건에 따라 완료시각이 다소 차이가 날 수 있습니다.)

# 현재 시각과 메뉴가 맞는지 확인합니다.

- 현재 시각을 맞추는 방법은 29쪽을 참조하십시오.
- 현재 시각이 맞지 않으면 예악시간도 틀려지므로 정확히 맞춥니다. (오전, 오후가 바뀌지 않도록 주의하십시오.)
- 메뉴가 틀리면 🚾 버튼을 눌러 메뉴를 선택해 주십시오.

(※ 주의 : 만능찜 예약은 tro Min 버튼을 눌러 만능찜 요리 시간을 설정합니다.)

## Timer 예약 버튼을 누릅니다.

- 😭 버튼을 누르면 "PRESET"이 깜빡이며, 기존에 설정된 예약시간이 나타납니다.
- 😭 버튼을 누른 후 7초 이내에 예약시각 설정을 시작해 주십시오
- ※ 초기 설정된 예약시각은 오전 6: 30입니다.
- ※ 뚜껑의 뚜껑결합 손잡이를 "Lock"에 맞추지 않고 📦 버튼을 누르면 "*E [] |* "이 나타나고, 작동되지 않습니다.





# 예약시각을 맞춥니다.

- ᆘ, ի 버튼을 눌러 원하는 예약시각을 맞춥니다.
- ※ 예약시각이 맞으면 맞추실 필요가 없습니다.
- 예)오전 7시 30분에 밥을 드시고 싶을 때
  - 「impr 버튼을 누른 다음("PRESET"표시가 깜박임)
  - 炊 버튼을 눌러 오전 7에 맞추고, ♥♥ 버튼을 눌러 30에 맞춥니다.
  - ( 🖙 버튼을 1시간, 🐚 버튼은 1분 단위로 맞출 수 있습니다.)





# 예약 취사 방법

# 4

# Timer 버트을 누릅니다.

- 표시창에 "PRESET COOK" 이 표시됩니다.
- 예약을 취소할 때는 Gancel 버튼을 누르십시오.
- ※ 한번 설정된 예약시각은 항상 기억되므로 예약시간 변경 없이
   예약취사를 하시려면 ( ) 버튼을 누르시면 됩니다.
- ※ 예약 진행 중에 현재시각을 확인하고 싶을 때는 💯 또는
  - Min 버튼을 누르면 2초 동안 현재 시각이 표시됩니다.





## 예약 취사시 유의 사항

- ▶ 쌀이 오래되어 매우 말라버린 경우에는 층밥 또는 싸라기 밥이 되는 수도 있습니다.
- ▶ 밥이 설익을 경우에는 물을 내솥에 표시된 물(水)높이 보다 반눈금 정도 더 넣어주십시오.
- ▶ 예약 시각을 변경할 경우에는 💬 버튼을 눌러 취소시킨 후 다시 시작하십시오.
- ▶ 최대 예약시간은 13시간이므로 13시간이하로 예약시간을 설정하십시오. 예약시간이 13시간을 초과할 경우 "/∃Ho"가표시되고 예약시간은 자동으로 13시간으로 변경됩니다.
  - 여름철에는 예약 시간이 7~8시간을 초과하면 밥이 쉰 냄새가 날 수 있으므로 주의해 주십시오.
- ▶ 예약설정 가능시간보다 짧을 경우 즉시 취사가 시작됩니다.

## \* 예약시간의 사용범위

메뉴 구분	Glutinous (백미)	Normal (김초밥)	Mixed (잡곡)	Dried (묵은쌀)	Nu Rung Ji (누룽지)	Sweet Pot. (고구마)	Multi Cook (만능찜)
예약설정 가능시간 (6인분 제품)	(37분+맞춤 밥맛시간) ~13시간	40분~ 13시간	(50분+맞춤 밥맛시간) ~13시간	(43분+맞춤 밥맛시간) ~13시간	43분~ 13시간	33분~ 13시간	설정시간 1분후 ~13시간
예약설정 가능시간 (8인분 제품)	(38분+맞춤 밥맛시간) ~13시간	44분~ 13시간	(54분+맞춤 밥맛시간) ~13 시간	(44분+맞춤 밥맛시간) ~13시간	45분~ 13시간	35분~ 13시간	설정시간 1분후 ~13시간




## 보온 요령

- ▶ 보온 기능을 12시간 이상 사용하게 되면, 밥이 변색되거나 냄새가 날 경우가 있습니다.
- ▶ 보온 또는 재가열시 반드시 뚜껑 결합 손잡이를 "Lock"쪽으로 체결하십시오 (뚜껑 열림 버튼 파손 및 보온성능에 영향을 줍니다.)
  - 취사가 끝나면 자동으로 보온 기능으로 전환됩니다. 밥이 다 되면 가능한 빨리 (5분이내) 골고루 잘 섞어 주십시오.
  - 3 잡곡, 현미는 특성상 백미보다 보온 상태가 좋지 않습니다. 장시간 보온을 하지 마십시오.
  - 5 식은 밥을 보온할 때 찬밥을 보온 중인 밥과 섞지 마십시오.
  - 7 뚜껑 안쪽(히터부)은 밥물 등이 묻어 이물질이 끼게 되므로 취사시 마다 깨끗하게 닦은 후 사용해 주십시오.

- 2 주걱을 넣은 채로 보온하지 마십시오. 특히, 나무주걱 등은 세균을 발생시켜 냄새의 원인이 됩니다.
- **4** 적은 양의 밥은 내솥 중앙에 모아서 보온 하십시오.
- 6 보온 중 전원을 항상 꽂아 주십시오. 뚜껑결합 손잡이를 "Lock" 쪽으로 돌리는 것이 보온 효과가 좋습니다.
- 8 보온 중 내솥의 가장자리나 증기배출구 하단부는 부분적으로 밥이 하얗게 변하고 부풀어 오를 수도 있습니다. 이럴 경우는 밥을 저어서 섞어 주십시오.

## 보온 온도 조절 방법

● **쉰냄새가 많이 나고 물이 많이 맺히는(밥이 삭는) 경우 :** 보온 온도를 1~2℃정도 높여 주십시오.



누른다.

5초이상 누른다.

\*\*제품 출고시 설정된 기준온도는 설명서와 다를 수 있습니다.

- 버튼을 눌러도 설정이 완료 됩니다.
- **밥 색깔이 심하게 누렇고 밥이 마르면서 냄새가 날 경우 :** 보온 온도를 1~2℃ 정도 낮추어 주십시오. 위와 같은 방법으로 ∰ 버튼을 눌러서 1~2℃ 정도 낮추시면 됩니다.
- ▶ 보온중에는 보온 강약조절이 가능합니다.
  - 🖤 버튼을 누르면 보온강약조절 MODE로 돌아갑니다.(초기상태 : H)
  - Wenny 버튼을 누를 때 마다 H → L 순으로 반복됩니다.
    - H: 보온시 뚜껑을 열 때 물이 많이 흐를 경우에 선택합니다.
    - L: 보온시 밥 가장자리에 밥퍼짐 현상이 생기는 경우에 선택합니다.
  - 7초 후 설정된 값이 자동으로 입력됩니다.( 🎥 😭 버튼 이외에 다른 버튼을 눌러도 입력이 완료됩니다.)
  - 입력중에 🔐 버튼을 누르면 이전 값을 유지한 채 보온 상태로 돌아갑니다.
- ▶ 보온중에는 보온 온도를 조정할 수 없습니다.
  - (ance) 버튼을 누른 후 (호텔) 버튼을 5초간 누른 후 보온 온도를 조정하십시오.

## 보온/재가열




## 재가열 기능 (보온 중인 밥을 금방 지은것 같이 따끈하게 해줍니다.)

▶ 재가열 기능은 보온중에만 동작합니다.

## 보온 중인 밥을 골고루 섞어 표면을 고르게 하십시오.


## 보온중일때.....





- 표면을 고르게 해 주시면 밥의 온도가 균일하게되며, 밥마름도 적어집니다.
- 보온중 (Min) 버튼을 누르면 현재 시각을 표시하고, (Min) 버튼을 누르면 보온경과 시간을 표시합니다.

역 무명결합 손잡이가 "Lock" 상태인지 확인하고 (Reheat Anys) 버튼을 누릅니다.



- 표시부의 " [ \_ ] " 표시가 시계방향으로 회전합니다.
- Hrs 버튼을 누르면 잔여시간이 표시되고
  - Min 버튼을 누르면 "[\_]"표시가 회전합니다.
- 약 9분 정도 지나면 완료음과 함께 재가열이 끝납니다.
- 재가열이 끝나면 다시 보온을 진행하며 보온경과 시간을 표시합니다.

## 재가열이 끝나면......

● 밥 전체를 잘 섞어서 바로 드시는 것이 좋으며 재가열은 1일 1~2회만 사용하십시오.


## 보온시 냄새가 날때

- ▶ 청소를 자주 해 주십시오. 특히, 뚜껑부의 청소상태가 나쁘면 세균이 번식하여 보온시 냄새가 날 수 있습니다.
- ▶ 외관상 깨끗하더라도 곳곳에 세균이 서식하여 보온시 냄새를 발생시킬 수 있으므로 냄새가 많이 날 경우는 물을 끓여 소독을 합니다.

물을 내솥의 "백미" 눈금 4인분 정도에 맞추고 식초를 1큰술 넣은 후 뚜껑을 닫고 버튼을 눌러 물을 끓입니다.

20~30분 정도 끓인 후 역한 버튼을 2초간 눌러 증기를 배출합니다. 물을 끓인 후 내솥을 반드시 깨끗이 씻어 냅니다.

▶ 탕이나 찜등의 요리를 한 후 깨끗이 씻어내지 않고 보온하면 밥에 냄새가 배어들 수 있습니다.



※ 손질을 할때는 반드시 물기가 없는 손으로 전원플러그를 빼고 본체의 열이 식은 후에 손질하십시오.

## 본체손질

본체 뚜껑을 닦으실 때에 벤젠, 신나, 세제 등은 사용하지 마십시오.


- ▶변색 및 변형의 원인이 됩니다.
- ▶깨끗한 행주로 닦아 주십시오.
- ▶본체는 물로 씻지 마십시오.



## 내솥(OVEN) 손질

내솥을 닦으실 때는 거친 수세미, 금속성 수세미, 솔, 연마제 등은 사용하지 마십시오.

- ▶코팅이 벗겨질 수 있습니다.
- ▶주방용 세제와 스폰지로 닦아 주십시오.



## 뚜껑 손질


● 뚜껑내부(안쪽)는 행주를 더운 물에 적셔 물기를 짠 다음 이물질을 닦아 주십시오.



## 본체 내부 손질


내솥을 들어 내고 바닥면(특히, 바닥부 온도 센서), 열판의 이물질은 반드시 제거한 후에 사용하십시오.

▶온도감지를 정확히 못하여 밥이 안되거나 제품의 이상동작, 화재의 원인이 됩니다.



## 물받이 손질

▶보온이나 취사 조리 후에는 항상 물받이에 있는 물을 버려주십시오. 물받이에 밥물이 고여 있는 경우 냄새의 원인이 됩니다.



## 압력추 밸브구멍 손질



# 고장신고 전에 확인하십시오.

증 상	확 인 사 항	조 치 사 항
밥이 되지 않을 때	• (	• 원하는 메뉴선택 후 반드시 바른을 기회 눌러 표시부에 "[]] "표시가 나타나는지 확인하십시오.
	• 취사중 정전이 되지 않았습니까?	* Turbo 미군글 나시 걸니 구립시고.
밥이 설익거나 퍼석할 때 또는 층밥이 될 때	• 계량컵을 사용하셨습니까? • 물 조절은 정확히 하셨습니까? • 쌀을 깨끗이 씻었습니까? • 쌀을 장시간 불린 후 취사하셨습니까? • 쌀을 개봉한지 오래되어 너무 말리있지 않습니까?	• 30~31쪽을 참조하여 올바르게 사용하십시오. • 물을 반눈금 정도 더 넣고 취사하십시오.
콩(잡곡)이 설익을 때	• 콩(잡곡)이 너무 마르지 않았습니까?	• 콩(잡곡)을 불리거나 삶아서 잡곡메뉴 에서 취사를 하십시오. 잡곡의 종류에 따라 설익을 수도 있습니다.
밥이 너무 질거나 된밥일 때	• 메뉴 선택은 맞게 하셨습니까? • 물 조절은 정확히 하셨습니까?	• 원하는 메뉴를 바르게 선택하십시오. • 물 조절을 정확히 하십시오.(30쪽 참조)
	• 뜸을 들이는 상태에서 뚜껑을 열지는 않았습니까?	• 취사 완료음이 울린 후 압력이 완전히 제거된 다음 뚜껑을 열고 밥을 섞어주십시오.
취사 도중 밥물이 넘칠 때	• 계링컵을 사용하셨습니까? • 물 조절은 확실히 하셨습니까? • 메뉴 선택을 확실히 하셨습니까?	• 30쪽을 참조하여 올바르게 사용하십시오.
보온중 냄새가 날 때	<ul> <li>뚜껑을 꼭 닫았습니까?</li> <li>보온중 전원 플러그가 콘센트에서 빠지지 않았습니까?</li> <li>12시간 이상 보온하였거나 너무 적은 밥을 보온하지 않았습니까?</li> <li>주걱이나 식은밥 혹은 다른 종류의 밥을 넣어서 보온하지 않았습니까?</li> </ul>	<ul> <li>뚜껑을 완전히 닫이주십시오.</li> <li>보온중 전원 플러그를 항상 꽂아 주십시오.</li> <li>보온시간은 가능한 12시간 이내로 하십시오.</li> <li>식은밥 또는 백미 이외의 메뉴는 보온하지 마십시오.</li> </ul>
" <i>E</i> " 표시가 나타날 때	• 온도감지기에 이상이 있을 때 나타납니다.	• 전원을 차단한 후 구입하신 대리점이나 서비스센터로 문의하십시오.
장시간 동안 취사가 완료되지 않고 "E 03"표시가 나타날 때	• 전원을 올바르게 사용하셨습니까?	<ul> <li>본 제품은 120V전용 제품입니다. 전원을 바르게 사용하십시오.</li> <li>제품에 이상이 생겨(히터 단선, 열량 부족 등) 장시간 밥이 완료되지 않을 때 나타나는 표시 입니다. 구입하신 대리점이나 서비스센터로 문의 하십시오.</li> <li>물만 넣고 장시간 가열할 경우에 "문 03" 표시가 나타나는 것은 정상입니다.</li> </ul>
버튼 입력시 " <b>싢」</b> " 표시가 나타날때	• 내솥이 제품에 들어 있습니까?	<ul> <li>내솥이 들어 있지 않은 상태에서는 버튼 조작이 되지 않습니다. 내솥을 넣어 주십시오.</li> </ul>
이 작동되지 않고 "EDI" 표시가 나타날때	• 뚜껑 결합 손잡이를 "Lock" 쪽으로 체결하셨습니까? • "Pressure" 램프에 불이 들어와 있습니까?	• 뚜껑 결합 손잡이를 완전히 체결합니다. 뚜껑 결합 손잡이가 완전히 체결되지 않으면 (전) ( ) ( 등의 버튼이 작동되지 않습니다.
취사 직후나 보온 중 밥에 서 이상한 냄새가 날 때	• 만능찜 등의 요리를 하신 후 청소를 깨끗이 하셨습니까?	• 뚜껑부의 패킹을 깨끗이 닦이낸 후 사용하여 주십시오.

# 고장신고 전에 확인하십시오.

증 상	확 인 사 항	조 치 사 항
밥이 심하게 눌을 때	• 온도감지기, 열판, 내솥외면에 밥알이 심하게 눌어 붙어 있거나 이물질이 있지는 않습니까?	• 온도감지기, 열판, 내솥외면의 이물질을 제거해 주십시오.
예약 취사 시각이 맞지 않을 때	• 현재 시각이 맞습니까?  • 오전, 오후를 잘못 선택하지 않았습니까? • 예약 시간을 13시간 이상으로 선택하지 않았습니까?	• 현재 시각을 맞추지 않으면 예약 시각에 취사가 완료되지 않습니다. 현재 시각을 맞추십시오. (☞ 29쪽 참조) • 오전, 오후를 확인하십시오. • 최대 예약시간은 13시간 입니다. (☞ 37~38쪽 참조)
뚜껑이 닫혀지지 않을 때	•뚜껑 결합 손잡이의 표시가 "Lock"을 가리키고 있습니까? •내솥에 밥이나 뜨거운 음식물이 들어 있지 않습니까? •내솥을 본체에 완전히 넣었습니까?	<ul> <li>뚜껑 결합 손잡이를 "Unlock" 상태로 놓고 닫아 주십시오</li> <li>압력추를 젖힌 다음 뚜껑을 닫습니다.</li> <li>내솥에 부착되어 있는 내솥 손잡이를 좌우로 돌려 본체에 완전히 안착시킵니다.</li> </ul>
뚜껑 결합 손잡이가 "Unlock" 쪽으로 움직이지 않을 때	<ul> <li>취사 중에 뚜껑 결합 손잡이를 돌리지 않았습니까?</li> <li>증기가 완전히 배출되지 않은 상태에서 뚜껑 결합손잡이를 돌리지 않았습니까?</li> </ul>	<ul> <li>취사 중에는 뚜껑이 열리지 않습니다. 뚜껑을 강제로 열지 마십시오.</li> <li>부득이한 경우는 한 버튼을 2초간 눌러 취소시킨 다음 압력추를 젖혀 증기를 완전히 빼낸 후 열어 주십시오</li> <li>압력추를 젖혀 증기를 완전히 빼낸 후 뚜껑을 열어 주십시오.</li> </ul>
뚜껑 결합 손잡이가 "Unlock"를 가리키고 있는데 도 뚜껑이 열리지 않을 경우		압력 때문입니다     압력추를 젖혀 증기를 완전히 빼낸 후 뚜껑을 열어 주십시오.
취사 또는 보온중 "딱딱" 소리가 날 때	• 취사 릴레이 소리가 아닙니까? • 내솥 밑면의 물기는 닦았습니까?	<ul> <li>릴레이의 "딱딱" 소리는 켜짐, 꺼짐의 작동소리로서 정상입니다.</li> <li>내솥 밑면에 물기가 있으면 "딱딱" 소리가납니다. 다음부터는 물기를 닦은 후 내솥을 넣어 주십시오.</li> </ul>
뚜껑 사이로 증기가 누설될때	•패킹에 이물질(밥알등)이 묻어있지 않았습니까? •패킹이 낡지 않았습니까?	<ul> <li>패킹을 행주나 부드러운 헝겊으로 깨끗이 닦은 후 사용하십시오.</li> <li>패킹주변은 항상 깨끗이 유지시켜 주십시오.</li> <li>증기가 누설되면 곧바로 전원 플러그를 뽑아 사용을 중지하시고 구입하신 대리점이나 서비스센터로 문의하십시오.</li> <li>패킹의 수명은 약 12개월이므로 1년에 한번씩 교체하여 사용하십시오. 낡은 패킹을 계속하여 시용시 증기가 누설되어 압력 취반이 되지 않을 수 있습니다.</li> </ul>
취시중 <sup>Cancel</sup> 버튼이 눌러지지 않을 때	• 내솥의 내부가 뜨겁지 않습니까?	<ul> <li>취시중 부득이하게 취사를 취소할 경우, 내솥 내부온도가 높으면, 안전을 위해 등에 버튼을 2초간 눌러야 취소됩니다.</li> <li>취사가 취소되면 자동 증기 배출 장치로 증기가 배출되면서 내용물이 비산할 수 있으므로 얼굴과 손등에 화상을 입을 수 있으니 주의하십시오.</li> </ul>
현미가 제대로 발아되지 않을 때	• 정격용량 이상의 현미를 넣고 발아시키지 않았습니까? • 묵은 현미를 사용하지 않았습니까?	•정격용량의 현미를 넣어주십시오. •묵은 현미나 오염된 현미를 사용했을 때 발아율이떨어질 수 있습니다.(☞ 35쪽 참조)

## **CUCKOO ELECTRIC RICE COOKER/WARMER** LIMITED WARRANTY

KEY Company, R&H Enterprise INC and Cuckoo Trading Canada. will repair at its option replace, without charge, your product which proves to be defective in material or workmanship under normal use, during the warranty period listed below from the data of original purchase. This warranty is good only to the original purchaser of the product during the warranty period. R&H Covers the east and the central districts, KEY Company covers the west and the Central Districts, Cuckoo Trading Canada covers the whole Canada.

## WARRANTY PERIOD

MODEL# **PARTS** #LABOR HOW SERVICE IS HANDLED

1YEAR

**FA06 Series** 1YEAR **FA08 Series** 

The East and the Central Districts

Call: 718 888 9144

Address: 14-10, 123rd Street, College Point, NY 11356, USA

The West and the Central Districts.

Call: 213 687 9828

Address: 700, Jackson Street, L.A, CA 90012, USA

Canada (Toronto)

Call: 416 878 4561 / 905 707 8224 Address: #D8-7398 Yonge Street Thorn Hill Ontario Canada L4J 8J2

Canada (Vancouver) Call: 604 540 1004

Address: 945 Lougheed Hwy Coquitlam BC Canada V3K 3T4

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. CUCKOO ELECTRONICS CO., LTD, SHALL NOT BE LIABLE FOR THE LOSS THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSE QUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY APPLICABLE TO THIS PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts: so these limitations or exclusions may apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

## THE ABOVE WARRANTY DOES NOT APPLY IN THESE CASES:

- \* To damages problems which result from delivery or improper installation.
- \* To damages problems which result from misuse, abuse, accident, alteration, or incorrect electrical current or voltage.
- \* To serve call which do not involve defective workmanship or material and explaining the operation of the unit.

Therefore, these costs are paid by the consumer. Customer assistance numbers:

To Prove warranty Coverage: 
Retain your Sales Receipt to prove data of purchase

Copy of your Sales Receipt must submitted at the time warranty service is provided.

To Obtain Product, Customer, or Service Assistance and Nearest Authorized service center, Parts Distributor or Sales Dealer:

parts Distributor or Sales Dealer: The Fast and the Central Districts

Call: 718 888 9144 Address: 14-10, 123rd street,

college point, NY 11356, USA

The west and the Central Districts. Call: 213 687 9828

Address: 700. Jackson Street, L.A. CA 90012, USA

Canada (Toronto) Call: 416 878 4561 / 905 707 8224

Address: #D8-7398 Yonge Street

Thorn Hill Ontario Canada L4J 8J2

Canada (Vancouver) Call: 604 415 9858

Address: 103-4501 North Road Burnaby BC Canada V3N

4R7